



## Section: SILENT 40 BATTERY CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2151					
1	1	1117-1317-01	Deck-yellow			
2	1	1117-1390-01	Handlebar w.switch			
3	1	1117-1322-01	Flap			
4	1	1117-1385-01	Motor mount			
5	2	1117-1371-01	Cap			
6	2	1117-1167-01	Wheel			
7	2	1117-1224-01	Wheel			
8	8	1117-1109-01	Ball bearing			
9	8	1117-1325-01	Bushing			
10	4	1111-2767-02	Wheel plate			
11	2	1117-1319-01	Hub cap			
12	4	1111-3132-01	Shoulder bolt			
13	4	1111-2756-01	Wheel cup-yellow			
14	2	1117-1326-01	Hub cap			
21	2	9899-3551-12	Screw			
22	1	1117-1384-01	Handlebar tube-R.H.			
22	1	1117-1383-01	Handlebar tube-L.H.			
23	1	1117-1345-01	Top collector-yello		Inkl.pos 24	
24	1	1111-2764-01	.Cover			
25	1	1117-1323-01	Collector half-L.H.			
26	1	1117-1324-01	Collector half-R.H.			
27	2	1111-0035-01	Locking knob			
28	2	9699-0025-02	Washer			
29	2	9847-7909-16	Screw			
30	8	9838-9110-12	Screw			
31	1	1111-2792-01	Spring			
33	4	1117-1059-01	Washer			
37	2	1111-3136-01	Washer			
38	1	9579-0008-00	Cable holder			
39	2	1117-1161-01	Wheel protection			