



Section: 321 DISCHARGE CHUTE CHUTE GUARD

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1321					
580	1	1812-1491-01	Chute ring			
581	4	1133-1014-01	Screw			
582	4	1133-1018-01	Chute guide			
583	1	1812-1499-01	Strip seal			
590	1	1133-1004-01	Lower chute			
591	2	9899-3516-16	Screw			
592	2	9727-3541-22	Nut			
595	1	1133-0970-01	Wire chute guide			
596	1	1133-0944-01	Torsion chute sprin			
597	1	1133-0945-01	Torsion chute sprin			
598	2	1133-0937-01	Acorn nut			
600	1	1133-0967-01	Upper chute			
601	1	1133-0969-01	Hinge wire			
602	1	9899-3632-12	Screw			
603	1	9699-0029-02	Flat washer			
604	1	1133-0932-01	T-knob			
605	1	9795-3631-02	Nut			
606	1	1133-1023-01	Screw			
607	1	9699-0029-02	Flat washer			
608	1	1812-0811-01	Locking nut			

test