



Section: VILLA SEAT

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			2858 2881				
			2855 2842 2843				
1	1	1	1	1134-0015-00		Seat spring	
2	1	1	1	1134-0493-00		Spring nut	
3	1	1	1	1134-2846-01		Tube	
4	1	1	1	1134-2847-01		Shaft	
5	1	1	1	1134-0022-00		Control rod	
6	1	1	1	1134-0050-00		Seat rod	
7	2	2	2	1134-1650-01		Tie bar	
8	1	1	1	1134-1652-01		Spring shackle	
9		1	1	1134-1685-03		Seat bracket-R.H.	2842, 2843 (US, CA)
9	1	1	1	1134-3618-01		Seat bracket-R.H.	
10		1	1	1134-1685-04		Seat bracket-L.H.	2842, 2843 (US, CA)
10	1	1	1	1134-3618-02		Seat bracket-L.H.	
11	1	1	1	1134-1883-01		Axle	
12	1	1	1	1134-2163-01		Rod	
13	1	1	1	1134-2166-01		Spacer	
14	1	1	1	1134-2454-01		Shaft	
15	2	2	2	9672-0006-02		Lock washer	
16	2	2	2	9672-0004-02		Lock washer	
17	4	4	4	9675-0017-02		Lock washer	
18	2	2	2	9799-0831-02		Nut	
30	1			1134-0800-06		Seat	
30		1	1	1134-2541-01		Seat	
40	2	2	2	1134-2961-01		Seat adapter	
41	2	2	2	1134-1711-01		Knob	
42	2	2	2	9699-0062-02		Flat washer	
43	4	4	4	9988-3616-16		Screw	
44	2	2	2	9898-0820-16		Screw	

test