



Section: TURBO 43-43S-43SE HANDLEBAR

Pos.	Quantity					Spare part No	Description	Kit	Notes	New
		1601			1499					
		1390	1690	1490	1699					
1	1	1	1	1	1	1111-2805-03	Front axle			
2	2	2	2	2	2	1111-1504-01	Retainer			
3	2	2	2	2	2	9947-0616-16	Screw			
4	1	1	1	1	1	1111-2818-02	Height adjusting ro			
5	2	2	2	2	2	9675-0011-00	Starlock			
6	1	1	1	1	1	1111-2819-01	Spring			
10	2	2	2	2	2	1111-1138-01	Spring			
11	2	2	2	2	2	1111-2784-01	Wheel assy			
12	1	1	1	1	1	1111-9047-01	.Ball bearing kit			
13	2	2	2	2	2	1111-1184-01	..Bearing cone			
14	2	2	2	2	2	1111-2785-01	Wheel cover			
15	2	2	2	2	2	9699-0100-02	Washer			
16	2	2	2	2	2	9943-0612-16	Screw			
17	2	2	2	2	2	1111-3084-01	Hub cap-yellow			
17	2	2				1111-3084-05	Hub cap-blue			
20	2	2	2	2	2	1111-3021-01	Handlebar attachmen			
21	4	4	4	4	4	9795-3531-02	Nut			
22	1	1	1	1	1	1111-3113-01	Handlebar-lower par			
23	4	4	4	4	4	1111-3023-01	Locking knob			
24	2	2	2	2	2	9899-3557-12	Screw	L = 57 mm		
25	2	2	2	2	2	9899-3545-12	Screw	L = 45 mm		
26	6	6	6	6	6	9699-0028-02	Flat washer			
27	2	2	2	2	2	9939-0820-16	Screw			
28	2	2	2	2	2	1111-3024-01	Attachment plate			
33	2	2	2	2	2	1111-0178-00	Reinforcement			
43	1	1	1	1	1	1111-3112-01	Handlebar-upper par			
44	1	1	1	1	1	1111-3062-01	Eyelink			
45		1				1111-2611-11	Throttle control	Honda		
46		1	1			9948-0645-16	Screw	L = 45 mm		
47	1	1	1	1	1	9948-0640-16	Screw	L = 40 mm		
47		1				9948-0660-16	Screw	L = 60 mm		
48	1	1	1	1	1	9747-0631-02	Lock nut	Honda 2 st/2 pcs		
52	1	1	1	1	1	1111-2953-01	Control handle			
53	1	1	1			1111-2968-01	Engine brake cable	Briggs & Stratton		
53				1	1	1111-2968-03	Engine brake cable			
53		1				1111-2968-05	Engine brake cable	Honda		
54	1	1	1	1	1	1111-2969-01	Cable attachment			
56	1	1	2	3	3	1111-2018-01	Cable holder	1601,1699 2 st/2 pc		
57	1	1	2	3	3	9836-9216-12	Screw	1601,1699 2 st/2 pc		
61				2	2	9836-9512-12	Screw			
62				1	1	9400-0218-00	Battery			
63	1	1	1	1	1	1111-2927-01	Battery holder			
64				1	1	9400-0219-00	Charger			
65				2	2	9838-9540-12	Screw	12-1699-12		
66				1	1	1111-2020-01	Housing	12-1699-12		
67				1	1	1111-2021-01	Cover	12-1699-12		
68				1	1	9838-9216-12	Screw	12-1699-12		
69				1	1	1111-2825-01	Harness			
70				1	1	9400-0186-00	Starting switch ass			
71				1	1	1134-2848-01	.Ignition key			
74				2	2	9838-9540-12	Screw	12-1499-12		
75				1	1	1111-2705-01	Cover	12-1499-12		
78				1	1	1111-2707-01	Housing	12-1499-12		
79				1	1	9401-0200-00	Cable holder	12-1499-12		