


4 - SPEED



## Section: TURBO 48-48S-48SE TRANSMISSION

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
		5802							
	5188	5202	5488	5489					
	5588	5288	5888	5889					
1	1	1	1	1	1111-2808-01		Rear axle		
2	2	2	2	2	1111-2814-01		Bushing		
3	4	4	6	6	9947-0616-16		Screw		
4	5	5	7	7	9838-9522-12		Screw		
5	1	1	1	1	1111-2798-01		Height adj.quadrant		
6	1	1	1	1	1111-2816-01		Height adj.lever		
7	1	1	1	1	1111-2817-01		Lever knob		
8	2	2	2	2	9943-0612-16		Screw		
9	2				9699-0037-02		Washer		
10	2	2	2	2	1111-2665-01		Wheel assy		
11	1	1	1	1	1111-9047-01		.Ball bearing kit		
12	2	2	2	2	1111-1184-01		. .Bearing cone		
15	2	2	2	2	9699-0100-02		Washer		
16	2	2	2	2	9943-0612-16		Screw		
17	2	2	2	2	1111-3085-01		Hub cap-yellow		
17			1	1	1111-3085-03		Hub cap-white		
17	2	2	2	2	1111-3085-05		Hub cap-blue		
20	2	2	2	2	1111-3060-01		Spring		
21	2				1111-2782-01		Wheel cover		
22		2	2	2	1111-2561-01		Cover plate		
23		1			1111-2915-01		Engine belt pulley		
24		1	1	1	9910-0612-16		Set screw		
25		1			1111-9061-01		V-belt		
26		1	1	1	1111-3046-01		Transmission		
27		1			1111-3047-01		Belt pulley		
28		1			9594-0235-00		Pin		
30		1			1111-2822-01		Tension spring		
31		2	2	2	1111-2382-01		Pin		
32		2	2	2	1111-2827-01		Drive key		
33		2	2	2	9404-0083-00		Seal ring		
36		4	4	4	9695-0013-00		Washer		
37		2	2	2	1111-2829-01		Lock washer		
38		2	2	2	1111-3075-01		Pinion-plastic whee		
39		2	2	2	1111-2830-01		Support washer		
41		2	2	2	9652-0010-04		Snap ring		
45		1	1	1	1111-2967-01		Clutch cable		
47		1	1	1	1111-2954-01		Control handle		
48	1	1	1	1	1111-2969-01		Cable attachment		
49		1	1		9948-0660-16		Screw	L = 60 mm	
49	1	1	1	1	9948-0640-16		Screw	L = 40 mm	
50	1	1	2	2	9747-0631-02		Lock nut		
51	1				1111-2924-01		Shaft		
52	2				9675-0017-02		Lock washer		
53	1	1	1	1	1111-2794-01		Cover-yellow		
53	1	1	1	1	1111-2794-12		Cover-grey		
53			1	1	1111-2794-04		Cover-red		
54		2	1		9838-9540-12		Screw		
55		1	1		1111-2971-01		Variator control		
57		1	1		1111-2941-01		.Knob		
58		1	1		1111-2943-01		Bracket		
61		1	1		9594-0026-00		Locating pin		
62		1	1		1111-2469-01		Attachment		
63		1	1		9943-0650-16		Screw		
64		1	1		1111-2423-01		Spacer		
65		1	1		1111-2433-01		Engine belt pulley		
66		1	1		1111-9065-01		V-belt		
67		1	1		1111-2942-01		Tension arm		
68		1	1		9997-0630-12		Screw		
69		1	1		1111-2747-01		Tension roller		
70		1	1		1111-2746-01		Belt pulley		
71		1	1		1111-3001-01		Variator assy		
73		2	2		9699-0060-02		Flat washer		