



test

Section: 524-SNOW BUSTER DRIVE TRAIN

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2824	2854				
190	1	1	1812-1218-01	Traction shaft		
191	2	2	1812-0328-01	Bushing		
192	2	2	9599-0073-02	Split pin		
193	1	1	1812-0364-01	Spring		
195	1	1	1812-1217-01	Traction spring lev		
196	1	1	9988-3516-16	Screw		
198	1	1	1812-0812-01	Locking nut		
210	1	1	1812-1269-01	Friction disc		
211	1	1	1812-1425-01	Grease zerk		
215	1	1	1812-1262-01	Traction hex shaft		
216	1	1	1812-0450-01	Bearing		
217	2	2	9699-0038-02	Flat washer		
221	1	1	1812-0402-01	Retaining ring		
222	1	1	1812-1238-01	Washer		
223	2	2	1812-1383-01	Ball bearing		
224	1	1	1812-1239-01	Square key		
225	1	1	1812-1236-01	Traction pulley		
226	1	1	1812-1237-01	Wave washer		
227	1	1	1812-1190-01	Flat washer		
228	1	1	9683-0025-02	Lock washer		
229	1	1	9988-3519-16	Screw		
230	1	1	1812-1178-01	Bearing & retainer		
231	2	2	1812-0385-01	Screw		
232	2	2	9683-0030-02	Lock washer		
235	1	1	1812-1204-01	Washer		
240	1	1	1812-1345-01	Hex shaft		
243	1	1	1812-1164-01	Retainer ring		
244	2	2	9699-0038-02	Flat washer		
245	1	1	1812-1313-01	Trunion bearing		
246	1	1	1812-9002-01	Friction disc		
247	3	3	9988-3516-16	Screw		
249	3	3	9795-3531-02	Nut		
250	1	1	1812-1204-01	Washer		
255	1	1	1812-1178-01	Bearing & retainer		
256	2	2	1812-0385-01	Screw		
257	2	2	9683-0030-02	Lock washer		
270	1	1	1812-1178-01	Bearing & retainer		
271	2	2	1812-0385-01	Screw		
275	1		1812-1213-01	Jack shaft	36T & 8T	
275	1		1812-1423-01	Jack shaft	36T & 7T	
276	1	1	1812-1178-01	Bearing & retainer		
277	2	2	1812-0385-01	Screw		
278	1	1	1812-1209-01	Chain		