



Section: FLAIL MOWER ART.NO 13-1977-12 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
1977						
1	1	1319-1761-01	Frame			
13	1	1319-1591-01	Pulley			
16	1	1319-1713-01	Belt guard			
17	1	1319-1765-01	Lift rod			
18	2	1319-1715-01	Side plate			
19	1	1482-0160-01	Spring			
20	1	1134-3193-01	Lever handle			
21	1	1134-3128-01	Height adj.quadrant			
22	1	1319-1770-01	Lift shaft			
23	1	1319-1737-01	Lift plate			
24	1	1319-1769-01	Lever			
25	1	1319-1719-01	Tension arm			
26	1	1319-1720-01	Rotor shaft			
27	1	1319-1772-01	Tine kit			
27A	104	1319-1721-01	.Tine-flail mower			
28	1	1319-1722-01	Screw			
29	2	1319-1628-01	Bearing			
30	2	1319-1766-01	Guard plate			
31	2	1319-1767-01	Guard			
32	1	1319-1725-01	Spring holder			
33	1	1482-0160-01	Spring			
35	2	1319-1726-01	Belt pulley		D = 105 mm	
36	1	1319-1727-01	Belt pulley		D = 150 mm	
37	1	1319-1728-01	Shaft			
38	1	1319-1729-01	Support pipe			
39	1	1134-9029-01	V-belt		= 9585-0055-00	
40	2	9549-0027-00	Ball bearing			
41	1	1319-1730-01	Lift rod			
43	1	9997-0860-16	Screw			
44	1	1319-1732-01	Collar			
45	6	9997-0816-16	Screw			
46	10	9747-0831-02	Lock nut			
46A	52	9747-0831-02	.Lock nut			
47	5	9997-0820-16	Screw			
48	8	9699-0028-02	Flat washer			
51	52	9997-0825-16	.Screw			
55	2	9747-1031-02	Lock nut			
56	4	9997-0812-16	Screw			
61	3	9699-0035-02	Flat washer			
65	1	9898-0816-16	Screw			
66	1	1134-0240-00	Shoulder screw			
69	1	1319-1739-01	Screw			
70	1	9787-1031-32	Nut			
71	1	9787-0831-32	Nut			
72	1	1134-3259-01	Wing nut			
77	2	9675-0012-02	Locking washer			
80	4	9997-0612-16	Screw			
84	1	1319-1775-01	Pin wrench			