



Section: PARK CLASSIC- PRESIDENT-PRO 16 POWER TAKE-OFF

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	1258	1358	1458				
	1442	1443	1446				
1	3	5	3	9739-0831-22		Nut	
2	1	1	1	1134-0143-00		Stop washer	
3	1	1	1	1134-2453-01		Locking pawl	
5	1	1	1	1131-1497-01		Spring	
8	1	1	1	1134-0027-01		Control lever	
8	1	1	1	1134-1396-02		Control lever	1442,1443,1446
9	1	1	1	1134-3573-01		Pto cable	
10	1	1	1	1134-1972-01		Disengaging lever	
11	2	2	2	9699-0025-02		Washer	
12	1	1	1	1134-0583-00		Plastic knob	
15	1	1	1	1134-0022-00		Control rod	
16	2	2	2	9672-0004-02		Lock washer	
17	1	1	1	1134-0153-00		Handle	
19	1	1	1	9847-8016-16		Screw	
23	1	1	1	1131-1506-00		Spring	
25	1	1	1	1134-1565-01		Spacer	
26	1	1	1	1134-1242-02		Spring	
27	1	1	1	1134-2018-01		Tensioning arm	
28	1	1	1	9997-1030-16		Screw	
30	1	1	1	1134-9027-01		Tension roller	
31	1	1	1	9799-1031-02		Nut	
32	1	1		1134-2020-01		Engine pulley	
32			1	1134-3394-01		Engine pulley	
32A	1	1	1	9997-1450-16		Puller-belt pulley	Tillbehör/accessory
33	1	1	1	9959-0820-16		Screw	
34	1	1	1	9997-0850-16		Screw	
35	1	1	1	9699-0056-02		Flat washer	
36	1	1	1	1134-0052-00		Bearing spacer	
37	1	1	1	1134-1769-02		Belt pulley assy	
38	2	2	2	9651-0040-04		.Retaining ring	
40	1	1	1	1134-0051-09		.Spacer	
41	2	2	2	9549-0019-00		.Ball bearing	
43	1	1	1	9699-0109-02		Flat washer	
44	1	1	1	1134-0222-00		Washer	
45	1	1	1	9959-1025-16		Screw	
46	1	1	1	1134-1730-01		Tension wheel arm	
47	2	2	2	1134-1888-01		Spacer	
48	1	1	1	1134-1770-01		Tension roller	
52	1	1	1	1134-1893-01		Spring attachment	
53	2	2	2	9699-0062-02		Flat washer	
54	1	1	1	9997-0865-12		Screw	
55	1	1	1	1134-1322-01		Spring	
56	1	1	1	9987-5338-12		Screw	
57	1	1	1	1134-9012-01		V-belt	= 9585-0056-00
60	1	1	1	1134-3654-01		Finger guard	
61	2	2	2	9739-0631-22		Nut	
62	2	2	2	9959-0612-16		Screw	
63	1	1	1	1134-2381-01		Belt guide	
64	2	2	2	9942-0816-16		Screw	
66		1		1134-3400-01		Angle plate	
67		2		9959-0816-16		Screw	
91	1	1	1	9739-1031-22		Nut	
92	1	1	1	1134-0041-03		Collar	
93	1	1	1	9997-1070-12		Screw	