



## Section: PARK PRESIDENT TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1358					
	1443					
1	1	1134-2020-01	Engine pulley			
2	1	9987-5338-12	Screw			
8	1	1134-9027-01	Tension roller			
9	1	1134-2015-03	Tension arm			
10	1	1134-9036-01	V-belt		= 9585-0083-00	
11	1	9799-1031-02	Nut			
12	1	9997-1030-16	Screw			
13	1	1134-0645-00	Spring			
14	1	1134-1565-01	Spacer			
15	1	1134-3364-01	Transaxle		Kanzaki K55B	
16	1	1134-3401-01	Bar			
17	1	9997-0860-16	Screw			
18	1	1134-0041-02	Idler wheel bush			
19	1	9747-0831-02	Lock nut			
20	1	1134-3407-01	Belt pulley			
21	1	9650-0015-04	Lock ring			
22	1	1134-3552-01	Fan			
23	4	9959-0612-16	Screw			
24	1	1134-3409-01	Control lever			
25	1	9595-0258-00	Locating pin			
26	1	1134-3414-01	Disengaging lever			
27	1	1134-2427-02	Spacer			
28	1	9942-0830-16	Screw			
29	3	9699-0056-02	Flat washer			
30	1	9696-0013-01	Bowed washer			
31	1	1134-3413-01	Chain lock			
32	2	9997-0875-12	Screw		L = 75 mm	
33	2	9997-0870-16	Screw		L = 70 mm	
34	4	9747-0831-02	Lock nut			
35	1	9959-0820-16	Screw			
36	1	9747-0831-02	Lock nut			
44	2	1134-3175-02	Rim-rear			
45	2	9545-0116-00	Tyre		16 x 7.50 - 8	
45A		9545-0203-00	Inner tube		Reservdel/spare par	
46	2	9545-0500-00	Valve			
47	2	9997-0840-16	Screw			
48	2	9747-0831-02	Lock nut			
49	2	1134-2471-01	Key			
57	1	1134-2766-03	Speed control wire			
58	1	9570-0001-00	Elbow link			
59	2	9739-0531-22	Nut			
60	1	1134-2021-01	Clamp			
61	1	9959-0816-16	Screw			
62	1	9739-0831-22	Nut			
63	1	1134-3400-01	Angle plate			
64	2	9959-0820-16	Screw			
65	2	9739-0831-22	Nut			
66	1	1134-3415-01	Control rod			
67	1	1134-2786-01	Plastic knob			
68	1	1134-2789-01	Bracket			
69	1	1134-2790-01	Rubber grommet			
70	1	9959-0816-16	Screw			
71	1	9739-0831-22	Nut			
72	1	9675-0012-02	Locking washer			
73	1	1134-2030-11	Clutch cable			
74	1	9646-0036-22	Rivet			
75	1	9675-0008-02	Locking washer			