



Section: VILLA SEAT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855					
	2856	2858	2881			
	2841	2842	2843			
1	1	1	1134-2541-01	Seat		
1	1		1134-0800-06	Seat		
2	2	2	1134-2961-01	Seat adapter		
3	2	2	1134-1711-01	Knob		
4	2	2	9699-0062-02	Flat washer		
5	4	4	9988-3616-16	Screw		
6	2	2	9898-0820-16	Screw		
12	1	1	1134-3800-01	Seat bracket-yellow		
13	1	1	1134-2163-01	Rod		
14	1	1	1134-2166-01	Spacer		
15	1	1	1134-0019-00	Spacer nut		
16	1	1	9595-0160-00	Locating pin		
17	2	2	9799-0831-02	Nut		
18	1	1	1134-2847-01	Shaft		
19	1	1	1134-2846-01	Tube		
20	2	2	1134-1650-01	Tie bar		
21	1	1	1134-3871-02	Pivot shaft		
22	2	2	9997-0816-02	Screw		
23	4	4	9699-0062-02	Flat washer		
24	2	2	9747-0831-02	Lock nut		
25	1	1	1134-3878-01	Seat bracket-R.H.		
25	1	1	1134-3877-01	Seat bracket-R.H.	2841, 2842, 2843	
26	1	1	1134-3878-02	Seat bracket-L.H.		
26	1	1	1134-3877-02	Seat bracket-L.H.	2841, 2842, 2843	
27	1	1	1134-3876-01	Spring shackle		
28	1	1	1134-3879-01	Seat spring		
29	1	1	1134-1883-01	Axle		
30	1	1	1134-0022-00	Control rod		
31	2	2	9672-0004-02	Lock washer		
32	1	1	1134-0050-00	Seat rod		
33	1	1	1134-2454-01	Shaft		
34	2	2	9672-0006-02	Lock washer		