



Section: 930-935-940 HANDLE STARTER IGNITION

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		3521	3522	3523			
6	1	1	1	M228929	Starter kit		
7	1	1	1	M229164	.Screw		
8	2	2	2	M235048	.Washer		
9	1	1	1	M235040	.Starter spring		
10	1	1	1	M235372	.Drum-rope kit		
11	1	1	1	M235042	..Starter rope	3 x 850 mm	
12	1	1	1	M235431	.Nut		
13	1	1	1	M235944	.Starter handle		
14	1	1	1	M229018	Plate		
15	1	1	1	M229082	Screw		
16	2	2	2	M240592	Nut		
17	1	1	1	M228653	Air conveyor		
18	1	1	1	M235218	Nut		
19	1	1	1	M235138	Flywheel assy		
20	2	2	2	M235518	.Starter pawl sprin		
21	2	2	2	M235517	.Starter pawl		
22	2	2	2	M235516	.Starter pin pawl		
23	1	1	1	M228416	Ignition assy		
24	1	1	1	M235238	.Spark plug wire		
25	1	1	1	M228139	Connector		
26	4	4	4	M235806	Screw		
38	6	6	6	M235802	Screw		
39	2	2	2	M240673	Spring		
84	4	4	4	M235205	Screw		
90	1	1	1	M240674	Spring		
106	2	2	2	M235216	Nut		
112	1	1	1	M246729	Handle		
113	1	1	1	M228913	.Throttle lever		
114	1	1	1	M228922	.Safety trigger		
115	1	1	1	M229088	.Trigger spring		
116	1	1	1	M229257	.Rod-throttle lever		
117	1	1	1	M228138	.Wire + switch		
118	2	2	2	M229087	.Pin		
119	1	1	1	M240675	Spring		
120	4	4	4	M235248	Washer		
121	1	1	1	M240669	Handle		