



Section: VILLA ENGINE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2855	2858	2881			
	2841	2842	2843	2856		
1	4	4	4	4	9747-0831-02	Lock nut
2	4	4	4	4	9997-0840-16	Screw
3		1	1	1	9500-9915-01	Tank bracket-front
4		2	2	2	9931-3619-16	Screw
5		1	1	1	9500-9916-01	Tank bracket-rear
6		2	2	2	9795-3631-02	Nut
7		1	1	1	1134-3582-01	Fuel tank
8		1	1	1	1134-2877-02	Fuel tank cap
9		1	1	1	1134-3586-01	Strap-short
10		1	1	1	1134-3587-01	Strap-long
11		2	2	2	9948-0630-16	Screw
12		2	2	2	9747-0631-02	Lock nut
13		1	1	1	1134-3224-01	Fuel shut-off valve
14		1	1	1	1134-3225-01	Grommet
15		1	1	1	1134-2975-01	Fuel hose
16		1	1	1	9500-9917-01	Heat guard
17		2	2	2	9578-0010-00	Cable clip
18		2	2	2	9578-0023-02	Hose clamp
19		2	2	2	9943-0510-16	Screw
20	1	1	1	1	1134-1364-02	Spacer ring
21	1	1	1	1	9600-0250-00	Key
22		1	1		1134-2350-01	Exhaust pipe
23		1	1		1134-0433-00	Muffler gasket
24		1	1		1134-2462-01	Lock
25		2	2		1134-1565-01	Spacer
26		2	2		9988-3651-12	Screw
27		1	1		1134-2394-01	Heat guard
28		2	2		9739-0831-22	Nut
29		1	1		1134-3869-01	Muffler
30		1	1		9578-0011-00	Clamp
31		1	1		9959-0820-16	Screw
32		1	1		1134-3724-01	Guard
33		1	1		9578-0022-00	Clamp
34		1	1		9842-0001-16	Screw
40	1	1	1	1	1134-1975-01	Gas control
41	1	1	1	1	9403-0035-10	Handle
42	2	2	2	2	9849-8009-16	Screw