



STIGA
546D
SPARE PARTS

Section: TURBO 48-48S-48SE HANDLEBAR FRONT WHEELS

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			5488 5489				
	5188 5288 5888 5889						
1	1	1	1	1111-2805-01		Front axle	
2	2	2	2	1111-1504-01		Retainer	
3	2	2	2	9947-0616-16		Screw	
4	1	1	1	1111-2818-01		Height adj.rod	
5	2	2	2	9675-0011-00		Starlock	
6	1	1	1	1111-2819-01		Spring	
10	2	2	2	1111-1138-01		Spring	
11	2	2	2	1111-2784-01		Wheel assy	
12	1	1	1	1111-9047-01		.Ball bearing kit	
13	2	2	2	1111-1184-01		..Bearing cone	
14	2	2	2	1111-2785-01		Wheel cover	
15	2	2	2	9699-0100-02		Washer	
16	2	2	2	9943-0612-16		Screw	
17	2	2	2	1111-3084-01		Hub cap-yellow	
17			2	1111-3084-05		Hub cap-blue	
20	2	2	2	1111-3021-01		Handlebar attachmen	
21	4	4	4	9795-3531-02		Nut	
22	1	1	1	1111-3022-01		Handle-lower	
23	4	4	4	1111-3023-01		Locking knob	
24	2	2	2	9899-3557-12		Screw	L = 57 mm
25	2	2	2	9899-3545-12		Screw	L = 45 mm
26	6	6	6	9699-0028-02		Flat washer	
27	2	2	2	9939-0820-16		Screw	
28	2	2	2	1111-3024-01		Attachment plate	
33	2	2	2	1111-0178-00		Reinforcement	
43	1	1	1	1111-2957-01		Handle-upper	
44	1	1	1	1111-3062-01		Eyelink	
47	1	1	1	9948-0640-16		Screw	L = 40 mm
48	1	1	1	9747-0631-02		Lock nut	
52	1	1	1	1111-2953-01		Control handle	
53	1	1	1	1111-2968-05		Engine brake cable	
54	1	1	1	1111-2969-01		Cable attachment	
56	1	1	2	1111-2018-01		Cable holder	
57	1	1	2	9836-9216-12		Screw	
61			2	9838-9512-12		Screw	
62			1	9400-0218-00		Battery	
63	1	1	1	1111-2927-01		Battery holder	
64			1	9400-0219-00		Charger	
69			1	1111-2825-01		Harness	
70			1	9400-0186-00		Starting switch ass	
71			1	1134-2848-01		.Ignition key	
74			2	9838-9522-12		Screw	
75			1	1111-2705-01		Cover	
78			1	1111-2707-01		Housing	
79			1	9401-0200-00		Cable holder	