



## Section: 524 GEAR CASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2824					
300	1	1812-0909-01	Gear case-RH			
301	1	1812-0908-01	Gear case-LH			
303	7	9988-3519-16	Screw			
304	6	9727-3541-22	Nut			
305	1	9795-3531-02	Nut			
306	1	1812-0856-01	Screw			
310	2	1812-0881-01	Oil seal			
311	2	1812-1360-01	Flange bearing			
312	2	1812-0857-01	Thrust washer			
313	1	1812-1402-01	Auger shaft			
314	1	1812-1361-01	Gasket			
315	1	1812-0862-01	Worm gear			
316	1	1812-1371-01	Woodruff key			
320	1	1812-1359-01	Bushing			
321	1	1812-1330-01	Input shaft			
322	1	1812-1321-01	Thrust collar			
323	1	1133-0395-01	Roll pin			
324	2	1812-0857-01	Thrust washer			
325	1	1812-0285-01	Needle bearing			
326	1	1812-1360-01	Flange bearing			
327	1	1812-0881-01	Oil seal			
340	1	1812-1434-01	Impeller			
341	2	1133-0395-01	Roll pin			

test