



Section: JB 35 ENGINE BELT TENSIONER

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1035					
1	4	9997-0845-12	Screw			
2	4	9699-0028-02	Flat washer			
3	4	9683-0030-02	Lock washer			
4	4	9799-0831-02	Nut			
7	1	1111-9029-01	Spark plug wrench			
8	1	1482-0656-01	Heat protection			
9	1	1482-0493-01	Belt tensioner assy			
10	1	1482-0781-01	.Bushing			
11	1	1482-0782-01	.Tension arm			
12	1	9699-0028-02	.Flat washer			
13	1	9683-0030-02	.Lock washer			
14	1	1482-0883-01	.Screw			
15	1	9799-1031-02	.Nut			
16	1	1482-0596-01	.Spacer			
17	1	1482-0550-01	.Tension roller-rev			
18	1	9683-0040-02	.Lock washer			
19	1	9997-1025-16	.Screw			
20	2	9915-0808-15	Set screw			
21	1	1482-0040-01	Key			
22	1	1482-0488-01	Belt pulley			
23	1	9699-0028-02	Flat washer			
24	1	9683-0025-02	Lock washer			
25	1	9799-0631-02	Nut			
26	1	1482-0628-01	Spring retainer			
27	1	1482-0535-01	Spring			
28	1	1482-0229-01	Spacer			
29	1	9898-0625-16	Screw			
30	1	1482-0545-01	Console			
31	1	9699-0028-02	Flat washer			
32	1	9683-0030-02	Lock washer			
33	1	9987-5189-12	Screw			