



STIGA
747A
SPARE PARTS

Section: SILENT 33 BATTERY SILENT 41 BATTERY MOTOR BLADE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4390	2151				
A01	1	1	1117-2076-01	Top housing (yellow		
A02	10	10	9836-9216-12	Screw		
A03	1	1	1117-2077-01	Upper housing (yell		
A04	1	1	1117-2137-01	Safety key plate		
A05	1	1	1117-2062-01	LED place		
A06	3	3	9836-9012-12	Screw		
A07	1	1	1111-3205-01	Safety key		
A08	1	1	1117-2087-01	LED circuit board		
A09	1	1	1117-2141-01	Cable	1175 mm	
B01	1	1	1117-2078-01	Battery house (gree		
B02	1	1	9579-0008-00	Cable holder		
B03	2	2	1117-2084-01	Connection		
B04	4	4	9683-0015-02	Lock washer		
B05	2	2	9836-9520-12	Screw		
B06	1	1	1117-2086-01	Motor plug set		
B07	1	1	9799-0431-02	Nut		
B08	1	1	1117-2140-01	IC card		
B09	1	1	1117-2079-01	Cover		
B10	2	2	9847-7716-16	Screw		
B11	1	1	9865-0408-16	Screw		
B12	2	2	9849-7909-16	Screw		
B13	1	1	1117-2108-01	Charging insulation		
B14	1	1	1117-2131-01	Rivet		
B15	1	1	1117-2105-01	Pad		
C01	2	2	9836-9216-12	Screw		
C02	1	1	1117-2080-01	Battery box cover		
C03	1	1	1117-2089-01	Charging plate		
C04	1	1	1117-2091-01	Cord		
C05	2	2	1117-2083-01	Battery	12 volt - 9 Ah	
C06	1	1	1117-2075-01	Battery box		
C07	1	1	9400-0262-00	Charger		
C99	1	1	1111-3122-01	Charging wire	Ej ill/not ill.	
D01	1	1	1117-2085-01	Motor		
D02	1	1	1117-2092-01	Motor base		
D03	1	1	1117-2082-01	Motor mounting plat		
D04	4	4	9836-9012-12	Screw		
E01	1	1	1111-3128-01	Blade holder		
E02	1	1	1111-0020-01	Support washer		
E03	1	1	1111-3135-01	Hexagonal washer		
E04	1	1	1111-3129-01	Blade nut		
E05	1	1	1111-3156-01	Blade wrench		
E06		1	1111-9101-01	Blade		
E06	1		1111-9083-01	Blade		