



Section: SNOW MASTER AUGER

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2824					
480	1	1812-1549-01	Auger pulley			
481	2	1812-1119-01	Bolt			
482	1	1812-1609-01	Key			
485	1	1812-1397-01	Spacer			
490	1	1812-1250-01	Retainer bearing			
491	1	1812-1383-01	Ball bearing			
493	3	9988-3619-16	Screw			
499	3	9795-3631-02	Nut			
500	1	1812-1532-01	Auger housing			
502	2	1133-0433-01	Fastener ratchet			
510	1	1812-1419-01	Scraper blade			
511	5	1812-1410-01	Carriage bolt			
514	5	9743-3521-32	Nut			
520	1	1812-1405-01	Auger-L.H.			
521	1	1812-1406-01	Auger-R.H.			
522	1	1812-9005-01	Shear bolt kit			
523	3	1812-0531-01	.Spacer			
524	3	1812-0812-01	.Locking nut			
525	2	1812-0878-01	Bearing			
526	6	9743-3621-32	Nut			
527	6	9988-3619-16	Screw			
540	2	1812-1479-01	Height adjust skid			
541	4	9899-3622-16	Screw			
544	4	9795-3631-02	Nut			

test