



Section: KANZAKI TRANSAXLE K46G-K46AG TRANSAXLE CASE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		K46					
		G					
		K46					
		AG					
3	1	1	1139-1302-01	Upper housing assy		Inkl. pos 4 - 5	
7	1	1	1139-1321-01	Lower housing			
8		2	1139-1300-01	Hose clamp			
9		1	1139-1299-01	Connector			
10		1	1139-1238-01	Breather collar			
11		1	1139-1100-01	Vent valve assy		Inkl. pos 12 - 13	
14	1	1	1139-1150-01	Magnet			
15	1	1	1139-1240-01	Holder-magnet			
16	1	1	1139-1303-01	Oil seal			
17	1	1	1139-1028-01	Spring			
18		1	1139-1324-01	Shaft-bypass			
18	1		1139-1251-01	Shaft-bypass			
19	1	1	1139-1189-01	Lever-bypass			
20	1	1	1139-1161-01	Ring			
21	1	1	1139-1275-01	Bore plug			
22	1	1	1139-1104-01	Snap ring			
23	1	1	1139-1279-01	Pin			
24	1	1	1139-1280-01	Pin			
25	2	2	1139-1117-01	O-ring			
26	1	1	1139-1119-01	Seal			
27	14	14	1139-0244-01	Tapping screw			
28	2	2	1139-1295-01	Tapping screw			
29	2	2	1139-1103-01	Seal washer			
30	2	2	1139-1123-01	Bolt			
31	1		1139-1306-01	Adapter			
32	2		1139-1300-01	Hose clamp			
33	1		1139-1301-01	Tube			

test