



Section: BE4700 COMBI (1800W)

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	704					
	602					
1	1	1117-1308-04	Deck-blue			
2	1	1117-1173-01	Shaft-backside			
3	2	9595-0212-00	Locating pin			
4	2	1117-3256-01	Wheel protection ca			
5	1	1117-1174-01	Height adjust lever			
6	2	1111-2663-01	Wheel			
7	2	9699-0037-02	Washer			
8	1	1117-3008-01	Baffle-rear			
9	18	9836-9516-12	Screw			
10	1	1117-1156-09	Rear flap-blue			
11	1	1117-1143-01	Shaft			
12	1	1117-1126-01	Spring-rear flap			
13	1	1117-1155-09	Flap holder-blue			
14	1	1117-3007-01	Baffle-front			
15	2	1111-3164-01	Wheel axle bolt			
16	8	9716-0831-02	Nut			
17	1	1117-1334-01	Front shaft			
18	2	9699-0078-02	Washer			
19	1	1117-1130-01	Connection rod			
20	2	1111-3163-01	Wheel			
21	2	1111-2804-06	Hub cap-grey			
22	2	1111-2815-06	Hub cap-grey			
23	6	1117-1131-01	Nut			
24	9	9699-0028-02	Flat washer			
25	2	1117-1363-01	.Handle support			
26	1	1117-3001-01	Mulch plug			
27	2	1117-1192-01	Isolation			
28	4	1117-1364-01	Screw			
29	4	9579-0008-00	Cable holder			
30	4	1117-3194-01	Locking knob			
31	8	9799-0831-02	Nut			
32	1	9799-0631-02	Nut			
33	1	1117-3198-01	Handle-lower part			
34	1	1117-3228-01	Blade			
35	1	1117-1218-01	Lower grass bag			
36	1	1117-1310-01	Handle support-R.H.			
37	1	1117-1309-01	Handle support-L.H.			
38	1	9997-0880-16	Screw			
39	2	1117-1161-01	Wheel protection			
40	1	1117-1151-01	Blade mount			
41	2	9865-0816-16	Screw			
42	1	1117-1357-01	.Window for cap			
43	2	9997-0870-16	Screw			
44	1	1117-1369-01	El.motor		1800 W	
45	1	1117-1299-01	Impeller			
46	1	9400-0224-00	Capacitor			
47	1	1117-1386-01	Motor cover-green		Inkl. pos 42	
48	2	9997-0614-16	Screw			
49	2	1117-1175-01	Washer			
50	1	1117-1120-01	Spring			
51	2	9591-0011-00	Pin			
52	2	1117-1083-01	Safety ring			
53	4	1111-2830-01	Support washer			
54	2	1111-3075-01	Pinion-plastic whee			
55	1	1117-1190-01	Clutch cable		Inkl. pos 72	
56	1	1117-1114-01	Support			
57	1	1117-1372-02	Motor mount-black			
58	1	9865-0616-16	Screw			
59	1	1117-3017-01	V-belt			
60	3	9678-0009-02	Lock washer			
61	10	9699-0062-02	Flat washer			
62	1	1117-1147-01	Transmission cap			
63	1	1117-3266-01	Pulley			
64	1	9907-0610-16	Screw			
65	1	1111-2927-01	Battery holder			
66	2	9549-0053-00	Ball bearing			

Section: BE4700 COMBI (1800W)

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	704					
	602					
67	2	1111-3256-01	Drive key			
68	1	1117-1373-02	Motor cover-black			
69	1	1117-3018-01	.Pulley			
70	1	1111-2382-01	.Pin			
71	1	1117-3227-01	Transmission assy		Inkl. pos 69, 70	
72	1	1134-3203-04	.Cable protector			
73	1	9849-7819-16	Screw			
74	4	1111-1273-01	Bushing			
75	1	1117-1245-01	Cable clamp			
76	3	1117-1361-01	Motor support			
77	2	9836-9116-12	Screw			
78	4	1117-1112-01	Bolt			
79	1	1117-1359-01	Clamp			
80	4	1111-3165-01	Bushing			
81	2	1117-1267-01	Bolt			
82	2	9898-0835-12	Screw			
83	1	1117-1358-01	Motor shaft protect			
84	1	1117-1169-01	Blade bolt			
85	1	1117-1111-01	Disc washer			
86	1	1117-1378-01	.Control handle			
87	1	1117-3211-01	Handle upper w.swit		Inkl. pos 25, 86	
88	2	9836-9512-12	Screw			
89	1	1117-1157-09	Grassbag cover-blue		Inkl. pos 92	
90	1	1117-3028-01	Assy kit			
91	2	9898-0845-12	Screw			
92	1	1117-1135-02	.Cover-black			

test