



## Section: SILENT 41 BATTERY CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2151					
1	1	1117-1317-01	Deck-yellow			
2	1	1117-3215-01	Handlebar w.switch			
3	1	1111-3103-01	Flap-yellow			
4	1	1117-1385-01	Motor mount			
5	2	1117-1371-01	Cap			
6	2	1111-3163-01	Wheel			
7	2	1111-3238-01	Wheel			
8	8	9549-0053-00	Ball bearing			
9	4	1117-1215-01	.Pin			
10	4	1117-1379-01	Wheel plate			
11	2	1111-2815-01	Hub cap-yellow			
12	4	1111-3164-01	Wheel axle bolt			
13	4	1117-1228-01	Adjusting lever		Inkl. pos 9	
14	2	1111-2804-01	Hub cap-yellow			
16	1	1111-3205-01	Safety key			
18	4	1111-2757-01	Motor attachment			
21	2	9898-0845-12	Screw			
22	1	1117-3206-01	Handle tube-left			
22	1	1117-3207-01	Handle tube-right			
23	1	1117-1345-01	Top collector-yello		Inkl. pos 24	
24	1	1111-2764-01	.Cover			
25	1	1111-3106-01	Collector-lower par			
26	1	1111-3116-01	Collector-lower par			
27	2	1117-3194-01	Locking knob			
28	2	9699-0028-02	Flat washer			
29	2	9847-7909-16	Screw			
30	11	9836-9516-12	Screw			
31	1	1111-2792-01	Spring			
33	4	9694-0003-00	Washer			
35	4	9836-9216-12	Screw			
36	2	1117-3022-01	Screw			
37	2	1111-3136-01	Washer			
38	1	9579-0008-00	Cable holder			
39	4	1117-1356-01	Lock washer			
43	1	1111-3156-01	Blade wrench			
44	1	1117-3023-01	Assy kit			
45	1	1117-3220-01	Assy kit			
46	4	1117-1382-01	Sector			
47	2	9699-0037-02	Washer			
48	4	9683-0030-02	Lock washer			
49	4	1117-1376-01	Wheel lever			
50	1	1117-1381-01	Shaft			
51	4	9716-0831-02	Nut			
52	1	1117-1380-01	Wheel shaft			
53	2	9799-0831-02	Nut			