



Section: TURBO 48S-48SE COLLECTOR 48S HERKULES MB482 CHASSIS

Pos.	Quantity	Spare part No				Description	Kit	Notes	New
					5586				
	5281				5686				
	5286				5604				
	5298	5203	5704	5698					
1	1				1111-3090-50	Chassis-alum.	12-5286-59		
1		1	1		1111-3090-04	Chassis-red			
1	1	1			1111-3090-01	Chassis-yellow			
2	1	1			1111-3283-01	Flap-yellow			
2	1		1	1	1111-3283-02	Flap-black			
3	1	1	1	1	1111-2792-01	Spring			
4	1	1			1111-2793-01	Flap attachm.-yello			
4	1		1	1	1111-2793-02	Flap attachm.-black			
5	3	3	3	3	9947-0616-16	Screw			
6	1	1			1111-2794-01	Cover-yellow			
6	1				1111-2794-02	Cover-black			
6			1	1	1111-2794-04	Cover-red			
7	3	3	3	3	9838-9522-12	Screw			
8	1	1	1	1	1111-3335-01	Rear attachment			
9	3	3	3	3	9947-0616-16	Screw			
10	1	1	1	1	9838-9522-12	Screw			
11	1	1	1	1	1111-2798-01	Height adj.quadrant			
12	2	2	2	2	9838-9522-12	Screw			
13	1	1	1		1111-2927-01	Battery holder	ej 12-5298-19		
14	1	1	1	1	1111-3236-01	Attachment-LH			
15	1	1	1	1	1111-3237-01	Attachment-RH			
16	4	4	4	4	9836-9520-12	Screw			
17	1	1	1	1	1111-3333-01	Mulch plug			
30	1	1	1	1	1111-9070-01	Blade holder			
31	1	1	1	1	1111-9090-01	Blade			
32	1	1	1	1	9696-0011-01	Washer			
33	1	1	1	1	9987-5251-12	Screw			
34	1	1	1	1	9600-0014-00	Key			
40	3	3	3	3	9955-3732-12	Screw			
41	1				1111-3287-01	Engine cover-black	12-5281-29		
41	1	1	1	1	1111-3352-01	Engine cover-black			
42	2	2	2	2	9500-9907-01	Screw			
42	2				9828-7942-12	Screw	12-5281-29		
50	1	1			1111-2840-01	Top collector-yello			
50	1		1	1	1111-2840-02	Top collector-black			
51	1	1	1	1	1111-2764-01	Cover			
52	1				1111-2841-02	Collector-lower par			
53	1				1111-2842-02	Collector-lower par			
54		1	1	1	1111-2844-01	Collecting bag-blac			
55		1	1	1	1111-2843-01	Wire clamp			
56		2	2	2	9838-9522-12	Screw			
57		2	2	2	9699-0100-02	Washer			
99	1	1			1111-2893-12	Decal kit			