



Section: SNOW MASTER DISCHARGE CHUTE

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|---------------------|-----|-------|-----|
| | 2824 | | | | | |
| 582 | 1 | 9899-3622-16 | Screw | | | |
| 583 | 1 | 1812-1163-01 | Plastic washer | | | |
| 584 | 1 | 9743-3621-32 | Nut | | | |
| 588 | 1 | 1812-0667-01 | Plastic washer | | | |
| 592 | 1 | 1812-1163-01 | Plastic washer | | | |
| 593 | 1 | 1812-0667-01 | Plastic washer | | | |
| 594 | 1 | 9699-0029-02 | Flat washer | | | |
| 595 | 1 | 9683-0030-02 | Lock washer | | | |
| 596 | 1 | 9699-0029-02 | Flat washer | | | |
| 597 | 1 | 1133-0932-01 | T-knob | | | |
| 598 | 1 | 9795-3631-02 | Nut | | | |
| 599 | 1 | 9899-3625-16 | Screw | | | |
| 600 | 1 | 1812-1692-01 | Chute assy | | | |
| 601 | 3 | 9899-3625-16 | Screw | | | |
| 602 | 3 | 9699-0029-02 | Flat washer | | | |
| 603 | 3 | 9743-3621-32 | Nut | | | |
| 604 | 1 | 1812-1436-01 | Chute flap | | | |
| 605 | 3 | 1812-1462-01 | Pop rivet | | | |
| 606 | 1 | 1812-1336-01 | Chute rotate collar | | | |
| 607 | 4 | 1812-1679-01 | Carriage bolt | | | |
| 608 | 4 | 9699-0028-02 | Flat washer | | | |
| 609 | 4 | 9743-3521-32 | Nut | | | |
| 610 | 1 | 1812-1366-01 | Chute rot. ring-inn | | | |
| 611 | 1 | 1812-1699-01 | Retainer ring-outer | | | |

test