



Section: PARK SENATOR TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6112						
1	1	1134-9027-01	Tension roller			
2	1	1134-2015-04	Tension arm			
3	1	1134-9057-01	V-belt		= 9585-0093-01	
4	1	9799-1031-02	Nut			
5	1	9997-1030-16	Screw			
6	1	1134-4337-01	Spring			
7	1	1134-1565-01	Spacer			
8	1	1134-3716-03	Transaxle		Peerless MST 205	
9	4	9997-0865-12	Screw			
10	4	9747-0831-02	Lock nut			
11	1	1134-3182-01	Belt pulley			
12	1	9600-0050-00	Key			
13	1	9650-0016-04	Lock ring			
14	1	1134-2045-01	Brake stop			
15	1	1134-2986-01	Bracket			
16	1	1134-3113-02	Spacer			
17	2	9942-0820-16	Screw			
18	1	9959-0816-16	Screw			
19	2	9739-0831-22	Nut			
20	1	1134-3289-01	Belt guide		H = 63 mm	
21	1	9942-0820-16	Screw			
22	1	9699-0056-02	Flat washer			
23	1	1134-3289-01	Belt guide		H = 63 mm	
24	1	9959-0820-16	Screw			
25	1	9739-0831-22	Nut			
26	1	1134-3289-02	Belt guide		H = 36 mm	
27	1	9739-0831-22	Nut			
28	1	9699-0056-02	Flat washer			

test