



Section: 1174 HST GEAR CASE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2846					
300	1	1812-0228-01	Gear case-RH			
301	1	1812-0227-01	Gear case-LH			
303	7	9987-5125-16	Screw			
304	8	9743-5121-02	Nut			
305	1	9987-5145-12	Screw			
306	1	1812-0346-01	Oil plug			
310	2	1812-0344-01	Ring			
311	2	1812-0343-01	Bearing			
312	2	1812-0345-01	Washer			
313	1	1812-1442-01	Auger shaft			
314	1	1812-0226-01	Gasket			
315	1	1812-0335-01	Worm gear			
316	1	1812-0409-01	Woodruffkey			
320	1	1812-0341-01	Ring			
321	1	1812-1259-01	Flange bearing			
322	1	1812-0857-01	Thrust washer			
323	1	1812-0285-01	Needle bearing			
324	1	1812-0857-01	Thrust washer			
326	1	1812-0307-01	Key			
327	1	1812-0336-01	Gear			
330	1	1812-0297-01	Bearing			
340	1	1812-1735-01	Impeller assy			

test