



Section: 1174 HST-1384 DISCHARGE CHUTE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2846	2862				
580	1	1	1812-1467-01	Upper chute		
582	2	2	1133-1023-01	Screw		
584	2	2	9743-3621-32	Nut		
585	2	2	1133-1023-01	Screw		
586	4	4	1812-0667-01	Plastic washer		
587	2	2	9743-3621-32	Nut		
600	1	1	1812-1473-01	Lower chute		
601	3	3	9899-3625-16	Screw		
602	3	3	9699-0029-02	Flat washer		
603	3	3	9743-3621-32	Nut		
604	1	1	1812-1569-01	Flap		
605	3	3	1812-1462-01	Pop rivet		
606	1	1	1812-1336-01	Chute rotate collar		
607	4	4	1812-1410-01	Carriage bolt		
609	4	4	1812-1760-01	Nut		
610	1	1	1812-1366-01	Chute rot. ring-inn		
611	1	1	1812-1787-01	Retainer ring-outer		

test