



Section: 928-928T CHUTE ROD

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------|---------------------|-------|-----|
| | 2837 | 2838 | | | | |
| 841 | 1 | 1 | 1812-1709-01 | Yoke and rod | | |
| 842 | 1 | 1 | 1133-0973-01 | Curved spring washe | | |
| 843 | 1 | 1 | 1812-1706-01 | Gear | | |
| 845 | 1 | 1 | 9599-0054-02 | Cotter pin | | |
| 846 | 1 | 1 | 1812-1697-01 | Bracket | | |
| 847 | 1 | 1 | 1812-1708-01 | Yoke adapter | | |
| 848 | 1 | 1 | 1812-1511-01 | Hair pin | | |
| 849 | 1 | 1 | 1812-1316-01 | Universal pin | | |
| 850 | 1 | 1 | 1812-1318-01 | Clevis pin | | |
| 851 | 1 | 1 | 9599-0033-00 | Split pin | | |
| 852 | 1 | 1 | 1812-1317-01 | Universal pivot blo | | |
| 854 | 1 | 1 | 1812-1168-01 | Handle | | |
| 855 | 2 | 2 | 1812-1171-01 | Washer | | |
| 856 | 1 | 1 | 1812-1483-01 | Retainer | | |
| 860 | 1 | 1 | 1812-0394-01 | Eyebolt | | |
| 861 | 1 | 1 | 1812-0203-01 | Grommet | | |
| 862 | 1 | 1 | 1812-1170-01 | Boot-eye bolt | | |
| 863 | 2 | 2 | 9743-3721-32 | Nut | | |
| 864 | 2 | 2 | 9699-0035-02 | Flat washer | | |
| 865 | 1 | 1 | 1812-1172-01 | Boot adaptor | | |
| 867 | 1 | 1 | 9743-3721-32 | Nut | | |
| 868 | 1 | 1 | 1812-1679-01 | Carriage bolt | | |
| 869 | 1 | 1 | 9743-3521-32 | Nut | | |
| 870 | 1 | 1 | 1812-1707-01 | Chute crank | | |

test