



Section: PARK DIESEL BODY WORK

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
6231						
1	1	1134-4929-01	Engine hood			
2	1	1134-3971-01	Engine cover-grey			
3	1	1134-4925-01	Air duct plate			
4	7	9675-0008-02	Locking washer			
5	1	1134-3943-01	Mud guard-LH, yell.			
6	1	1134-3943-02	Mud guard-RH, yell.			
7	4	9893-0616-16	Screw			
8	2	1134-4176-01	Clips			
9	2	9699-0025-02	Washer			
10	2	9747-0631-02	Lock nut			
11	2	1134-0225-00	Support plate			
12	6	9945-0816-16	Screw			
13	4	9699-0056-02	Flat washer			
14	1	1134-4220-02	Bumper-grey			
15	6	9893-0616-16	Screw			
16	2	1134-4176-01	Clips			
17	1	1134-4216-01	Front plate-grey			
18	1	1134-3984-01	Front plate upper-g			
19	2	9840-8009-16	Screw			
20	2	9946-0525-16	Screw			
21	1	1134-4360-01	Cover-inner			
22	1	1134-3979-01	Cover-outer			
23	5	9946-0525-16	Screw			
24	2	9950-0570-12	Screw			
25	2	9747-0531-02	Nut			
26	1	1134-4152-01	Cover			
27	3	9893-0616-16	Screw			
28	2	9893-0616-16	Screw			
29	2	9739-0631-22	Nut			
30	1	1134-4798-01	Spoiler-grey			
31	4	9893-0616-16	Screw			
32	1	1134-4012-03	Support-RH			
33	1	1134-4012-04	Support-LH			
34A	1	9959-0820-16	Screw		L = 20 mm	
34B	1	9959-0830-16	Screw		L = 30 mm	
35	2	9739-0831-22	Nut			
36	1	1134-3985-01	Cover			
37	2	9893-0616-16	Screw			
38	1	1134-3970-01	Moulding left-grey			
39	1	1134-3970-02	Moulding-RH, grey			
40	4	9893-0616-16	Screw			
41	1	1134-4799-01	Handle			
42	2	9836-9512-12	Screw			
43	1	1134-9028-01	Rubber strap kit		Sats 3 st/kit of 3	
44	1	9632-0516-00	Pop rivet			
45	1	9699-0120-02	Washer			
46	1	9405-0029-00	Knob			
47	1	9632-0513-00	Pop rivet			
48	1	9699-0120-02	Washer			
49	1	1134-4800-01	Inner mud guard-RH			
50	1	1134-4801-01	Inner mud guard-LH			
51	4	9893-0616-16	Screw			
52	2	1134-4176-01	Clips			
53	2	9405-0029-00	Knob			
54	2	9632-0513-00	Pop rivet			
55	2	9699-0120-02	Washer			
56	2	9893-0616-16	Screw			
57	2	9747-0631-02	Lock nut			
58	1	9403-0047-01	Cover			
59	1	1134-4593-08	Decal kit		Diesel	