




Genuine Spare Parts



Joist
Spareparts
Joist





Utgåva Issue		Bildnr Picture No		SP 340 VEVHUS KEDJEBROMS		SP 340 CRANKCASE CHAIN BRAKE		Sida Page	
2006- 12		2160						356	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4110 -11								
1	1			1911-4208-01	Vevhus kpl.....	Crankcase assy		Inkl. pos 12- 14, 22	
2	1			1911-3534-01	Tanklock	Tank cap			
3	1			1911-3534-01	Tanklock	Tank cap.....			
4	1			1911-3539-01	Oljepump	Oil pump		D = 8 mm	
5	1			1911-3462-01	Distans	Spacer			
6	2			1911-3247-01	Skruv	Screw			
7	1			1911-3368-01	Hållare	Retainer			
8	1			1911-3225-01	Svärd	Bar		14" (3/8"x0.050)	
9	1			1911-3295-01	Kedjespännskruv	Chain tension screw			
10	1			1911-3942-01	Skruv	Screw			
11	1			1911-3387-01	Kedjespännare	Chain tensioner			
12	1			1911-3445-01	• Lock- oljetillförsel	• Cap- oil supply			
13	1			1911-3952-01	• Förstärkning	• Reinforcement.....			
14	1			1911-3563-01	• Oljeslang	• Tube			
15	1			1911-4168-01	Svärdplatta	Bar plate.....			
16	1			1519-9001-50	Kedja (50E).....	Chain (50E).....		91VG (3/8")	
17	1			1911-3541-01	Kopplingshus- gul.....	Clutch housing- yellow		Inkl. pos 20	
18	1			1911-3505-01	Bränsleledning	Fuel line.....			
19	1			1911-3150-01	Bränslefilter	Intake filter			
20	1			1911-3296-01	• Mutter	• Nut			
21	1			1911-3938-01	Förstärkning	Reinforcement			
22	1			1911-3560-01	• Andningsventil	• Breather valve			
23	1			1911-3249-01	Skruv	Screw			
24	1			1911-3519-01	Kedjeskydd	Chain cover		14"	
31	1			1911-3364-01	Bromsband	Brake band			
32	1			1911-3216-01	Bricka	Washer			
33	1			1911-3249-01	Skruv	Screw			
34	1			1911-3540-01	Kedjebromsarm	Chain brake lever			
35	1			1911-3310-01	Pinne	Pin			
36	1			1911-3366-01	Fjäder	Spring			
37	1			1911-3482-01	Bromskåpa	Brake cover			
38	2			1911-3002-01	Skruv	Screw			
39	1			1911-3415-01	Fjäder	Spring			
40	1			1911-3361-01	Bromsplåt	Brake plate			
41	1			1911-3311-01	Pinne	Pin			
42	1			1911-3358-01	Bussning	Bushing			
44	3			1911-3001-01	Skruv	Screw			
45	1			1911-3543-01	Cylinderkåpa- gul	Cylinder cover- yellow			
46	1			1911-3575-01	Handskydd	Hand guard			
47	1			1911-3617-01	Luftfilter	Air filter			
49	1			1911-3487-01	Primerknapp	Air purge cap button			
50	1			1911-3416-01	Fjäder	Spring			
51	1			1911-3486-01	Primerhandtag	Air purge button			



Utgåva Issue 2006-12	Bildnr Picture No 2161	SP 340 HANDTAG START	SP 340 HANDLE STARTER	Sida Page 358
----------------------------	------------------------------	----------------------------	-----------------------------	---------------------

Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110 -11								
1	1				1911-3573-01	Handtag	Handle		
2	1				1911-3574-01	Handtagskåpa	Handle cover		
3	1				1911-3453-01	Gasreglage	Throttle lever		
4	1				1911-3417-01	Fjäder	Spring		
5	1				1911-3454-01	Säkerhetsspärr	Safety lever		
6	3				1911-3414-01	Fjäder	Spring		
7	2				1911-3367-01	Bricka	Washer		
8	3				1911-3002-01	Skruv	Screw		
9	6				1911-3248-01	Skruv	Screw		
10	1				1911-3007-01	Skruv	Screw		
11	1				1911-3022-01	Mutter	Nut		
12	3				1911-3015-01	Bricka	Washer		
21	1				1911-3542-01	Start kpl- gul	Starter assy- yellow		Inkl. pos 22 - 31
22	1				1911-3130-01	• Startsnöre	• Starter cord		
23	1				1911-3479-01	• Starthandtag	• Starter handle		
24	3				1911-3001-01	• Skruv	• Screw		
25	1				1911-3176-01	• Startfjäder	• Starter spring		
26	1				1911-3372-01	• Bussning	• Bushing		
27	1				1911-3096-01	• Skiva	• Disc		
28	1				1911-3483-01	• Linhjul	• Starter pulley		
29	2				1911-3480-01	• Startspärr	• Starter hook		
30	1				1911-3484-01	• Fäste- startspärr	• Guide- starter hook		
31	1				1911-3423-01	• Hållare	• Retainer		



Utgåva Issue		Bildnr Picture No		SP 340 CYLINDER- VEVAXEL FÖRGASARE	SP 340 CYLINDER- CRANKSHAFT CARBURETTOR	Sida Page	
2006- 12		2162				360	
Pos. Fig.	Antal/Quantity		Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4110 -11						
1	1		1911-3280-01	Mutter.....	Nut.....		
2	1		1911-3268-01	Bricka.....	Washer.....		
3	1		1911-3567-01	Svånghjul.....	Flywheel.....		
4	1		1911-3048-01	Svånghjulskil.....	Flywheel key.....		
5a	1		1911-3301-01	Tätningring.....	Seal ring.....		
5b	1		1911-3302-01	Tätningring.....	Seal ring.....		
6	2		1911-3297-01	Kullager.....	Ball bearing.....		
7	2		1911-3072-01	Bricka.....	Washer.....		
8	1		1911-3532-01	Vevaxel kpl.....	Crankshaft assy.....		Inkl. pos 19
9	1		1911-3488-01	Dammskydd.....	Dust guard.....		
10	1		1911-3538-01	Koppling.....	Clutch.....		
11	1		1911-3041-01	Nållager.....	Needle bearing.....		
12	1		1911-3507-01	Kedjedrev.....	Sprocket.....		
13	1		1911-3338-01	Drevbricka.....	Sprocket washer.....		
14	1		1911-3330-01	Låsring.....	Circlip.....		
15	2		1911-3069-01	.. Låsring.....	.. Lock ring.....		
18	1		1911-3051-01	.. Kolvbult.....	.. Piston pin.....		
19	1		1911-3042-01	• Nållager.....	• Needle bearing.....		
20	4		1911-3006-01	Skruv.....	Screw.....		
21	4		1911-3274-01	Bricka.....	Washer.....		
22	1		1911-3304-01	.. Kolvring.....	.. Piston ring.....		
23	1		1911-3861-01	• Kolv kpl.....	• Piston assy.....		Inkl. pos 15, 18, 22
24	1		1911-3597-01	Cylinder- kolv kpl.....	Cylinder- piston assy.....		Inkl. pos 23
25	1		9400-0258-00	Tändstift.....	Spark plug.....		Champion CJ7Y
26	1		1911-3470-01	Tändstiftshatt.....	Spark plug cover.....		
27	1		1911-3421-01	Fjäder.....	Spring.....		
28	1		1911-3434-01	Skydd.....	Protection.....		
29	1		1911-3053-01	Stoppkontakt.....	Stop switch.....		
32	1		1911-3321-01	Jordkabel.....	Ground cable.....		
33	1		1911-3320-01	Elektronikspole.....	Electronic coil.....		
34	1		1911-3418-01	Fjäder.....	Spring.....		
35	2		1911-3017-01	Bricka.....	Washer.....		
36	2		1911-3251-01	Skruv.....	Screw.....		
37	1		1911-3247-01	Skruv.....	Screw.....		
41	2		1911-3007-01	Skruv.....	Screw.....		
42	1		1911-3513-01	Ljuddämpare.....	Muffler.....		
43	1		1911-3442-01	Packning.....	Gasket.....		
45	1		1911-3506-01	Bränsledning.....	Fuel line.....		
47	1		1911-3451-01	Chokereglage.....	Choke lever.....		
48	1		1911-3990-01	Insugningsrör.....	Air intake manifold.....		
48A	1		1911-3951-01	Kabel.....	Cable.....		
49	2		1911-3264-01	Skruv.....	Screw.....		
50	1		1911-3465-01	Gummihylsa.....	Grommet.....		
51	1		1911-4447-01	Förgasare kpl.....	Carburettor assy.....		WT-718B
52	1		1911-3440-01	Packning.....	Gasket.....		
53	1		1911-3545-01	Gaswire m.hölje.....	Throttle cable w.sh.....		
54	1		1911-3485-01	Insugningsrör.....	Intake manifold.....		
55	1		1911-3444-01	Packning.....	Gasket.....		
56	1		1911-3460-01	Primerpump.....	Primer pump.....		
58	1		1911-3613-01	Membran- packningssats	Diaphragm- gasket set.....		
59	1		1911-3615-01	Packningssats.....	Gasket set.....		
60	2		1911-3435-01	Cylinderpackning.....	Cylinder gasket.....		

X