


Genuine Spare Parts

SP 420








SP 420 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	6995173	Mutter	Nut	
2	1	6995289	Kil	Flywheel Assy	
3	1	6995281	Vevhus	Crankcase Ass.Y	
4	1	6995278	Tätningring	Seal Ring	
5	2	6995277	Kullager	Bearing	
6	1	6995283	Packning	Gasket Set	KIT POS. 100
7	1	6995255	Låsring	Elastic Ring	.
8	1	6995257	Tätningring	Seal Ring	.
9	2	6995028	Styrpinne	Pin	.
10	4	6995276	Skruv	Screw	.
11	1	6995314	Vevaxel	Crankshaft	.
12	2	6995265	Bricka	Washer	.
13	1	6995304	Lager	Bearing	.
14	2	6995256	Låsring	Washer, Piston Pin	.
15	1	6995313	Kolvbult	Piston Pin	.
16	1	6995287	Kolv	Piston	.
17	2	6995258	Kolvring	Piston Ring	.
18	1	6995283	Packning	Gasket Set	KIT POS. 100
19	1	6995284	Cylinder	Cylinder Assy	.
20	6	6995259	Skruv	Screw	.
21	1	6995320	Lock	Cover	.
22	2	6995322	Packning	Gasket	.
23	1	6995321	Lock	Cover	.
24	1	3210024	Tändstift	Spark Plug	.
25	4	6995319	Skruv	Screw	.
26	2	6995261	Skruv	Screw	.
27	1	6995290	Elektronikspole	Electronic Coil	.
30	2	6995293	Skruv	Screw	.
31	1	6995283	Packning	Gasket Set	KIT POS. 100
32	1	6995292	Ljuddämpare	Muffler Assy	.
33	1	6995294	Deflektor	Deflector	.
34	1	6995062	Skruv	Screw	.
35	2	6995064	Mutter	Nut	.
41	1	6995283	Packning	Gasket Set	KIT POS. 100
43	1	6995285	Insugningsrör	Intake Manifold	.
44	1	6995283	Packning	Gasket Set	KIT POS. 100
45	1	6995291	Förgasare	Carburettor	.
46	1	23878013/0	Skruv	Screw	.
47	1	6995267	Luftintag	Air Manifold	.
48	2	6995271	Skruv	Screw	.
49	1	6995323	Packning	Gasket	.
50	1	6995282	Koppling kpl	Clutch Ass.Y	.
51	1	6995272	Fjäder	Spring	.
52	1	6995266	Bricka	Sprocket Washer	.
53	1	6995269	Kopplingshjul	Drum Ass'Y, Clutch	.
54	1	6995230	Nållager	Needle Bearing	.
55	1	6995311	Oljepump	Oil Pump Assy	.
56	1	6995270	Skruvhylsa	Female Screw	.
57	4	6995261	Skruv	Screw	.
58	1	6995305	Pumplock	Cover Pump	.
60	1	6995295	Rör	Tube	.
61	1	6995280	Pickup Oil	Pickup Oil	.
62	1	6995296	Oljefilter	Oil Filter Ass.Y	.
63	1	6995223	Bricka	Washer	.
71	4	6995062	Skruv	Screw	.
72	1	6995002	Skruv	Screw	.
73	1	6995297	Vevhus	Crankcase Ass.Y	.
74	1	6995068	Lock	Cap	.
75	2	6995253	Skruv	Screw	.
76	1	6995038	Dämpement	Shock Absorber	.
77	1	6995303	Vibrationsdämpare	Shock Absorber	.
78	1	6995274	Lock	Cap	.
81	1	6995279	Kedjestopp	Chain Guard	.
82	1	6995262	Skruv	Screw	.
83	1	6995259	Skruv	Screw	.
84	1	6995263	Plåt	Plate	.
100	1	6995283	Packning	Gasket Set	.
101	1	6995315	Membran-packn.sats	Diaph.-Gasket Set	.
102	1	6995288	Kit Repair	Kit Repair	.





SP 420 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	3	23878013/0	Skruv	Screw	.
2	1	83058009/0	Start kpl	Starter Assy Yellow	.
3	1	23044208/0	Hylsa	Grommet	.
4	1	3750067	Starthandtag	Starter Handle	.
5	1	23234001/0	Startsnöre	Starter Cord	.
6	1	23430562/0	Startfjäder	Starter Spring	.
7	1	23604002/0	Linhjul	Starter Pulley	.
8	1	23657004/0	Bricka	Washer	.
9	1	23878013/0	Skruv	Screw	.
10	1	23107502/0	Luftledare	Air Conveyor	.
15	1	6995299	Handtag kpl	Handle Assy	.
16	1	6995114	Fjäder	Spring	.
17	1	6995264	Gasreglage	Throttle Lever	.
18	1	6995016	Spännstift	Pin	.
21	1	6995307	Gasreglagelänk	Throttle Rod	.
22	1	6995135	Säkerhetsspärr	Safety Lever	.
23	1	6995312	Styre-överdel	Handle, Upper Part	.
24	1	6995254	Skruv	Screw	.
25	1	6995268	Lock	Cap	.
26	1	6995273	Lock	Cap Oil Tank	.
28	1	6995226	Brytare	Switch	.
29	1	6995310	Stoppkabel	Stop Wire	.
30	1	6995306	Jordkabel	Earth Cable	.
31	1	6995232	Gummihylsa	Grommet	.
32	1	6995260	Tanklock	Fuel Tank-Cap Ass.Y	.
34	1	6995300	Bränslefilter	Intake Filter Assy	.
36	1	6995221	Vevhusventil	Breather Valve Ass.Y	.
37	1	6995298	Andningsventil	Breather Valve Ass.Y	.
38	1	6995002	Skruv	Screw	.
39	1	6995301	Fjäder	Spring	.
40	1	6995062	Skruv	Screw	.
41	1	6995002	Skruv	Screw	.
42	1	6995309	Plåt	Plate	.
43	1	6995302	Fjäder	Spring	.
45	4	23878013/0	Skruv	Screw	.
46	1	23087005/0	Cylinderkåpa	Cylinder Cover Yellow	.
47	1	23653500/0	Lock	Cap	.
49	1	6995308	Hylsa	Grommet	.
50	1	23275006/0	Hylsa	Grommet	.
51	1	23315062/0	Chokearm	Choke Lever	.
52	1	23220001/0	Luftfilter	Air Filter	.
53	1	23090012/0	Luftfilterkåpa	Filter Cover Yellow	.
54	1	83593500/0	Låsratt	Knob Ass'Y	.
61	4	6995254	Skruv	Screw	.
62	1	6995286	Handtag	Handle	.
65	1	23900302/0	Svärd	Guide Bar 16"	16" 325" .050" (1.3 mm)
66	1	4113712	Kedja	Chain 16"	16" 325" .050" (1.3 mm) - 66E
71	1	83059007/0	Kopplingshus	Clutch Ho. W/Br. Assy Yellow	.
72	2	23878014/0	Skruv	Screw	.
73	1	23109516/0	Bromskåpa	Brake Cover	.
74	1	23120000/0	Mutter	Nut	.
75	1	23657005/0	Bricka	Washer	.
76	1	23430564/0	Fjäder	Spring	.
77	1	23665000/0	Stift	Roller	.
78	1	83315050/0	Kedjebromsarm	Chain Brake Lever	.
79	1	23044207/0	Bussning	Bushing	.
80	1	23430563/0	Fjäder	Spring	.
81	1	23080000/0	Motvikt	Balance Weigth	.
82	1	23044210/0	Bussning	Bushing	.
83	1	23878012/0	Skruv	Screw	.
84	1	23670000/0	Plåt	Plate	.
85	1	23430559/0	Fjäder	Spring	.
86	1	23430565/0	Fjäder	Spring	.
87	1	23315061/0	Arm	Lever	.
88	1	23665001/0	Stift	Pin	.
89	1	23448002/0	Bromsband	Brake Band	.
91	1	23878011/0	Skruv	Screw	.
92	1	23796004/0	Mutter	Bar Adjusting Block	.
93	1	23510093/0	Sprint	Pin	.
94	1	23311004/0	Platta	Plate	.
95	2	23878014/0	Skruv	Screw	.
96	2	6995097	Mutter	Nut	.
100	1	4181307	Kedjeskydd	Chain Cover	.