


Genuine Spare Parts

SPR 270








SPR 270 - Model Year 2008


Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	6995173	Mutter	Nut	
2	1	6995207	Svånghjul	Flywheel Assy	
3	2	6995224	Skruv	Screw	
4	2	6995208	Startspärr	Flywheel Starter Hook	
5	2	6995250	Fjäder	Flywheel Spring	
6	2	6995225	Bricka	Washer	
7	1	6995247	Tätningssring	Seal Ring	
8	2	6995170	Kullager	Ball Bearing	
9	1	6995018	Kil	Flywheel Key	
10	1	6995202	Vevaxel	Crankshaft	
11	2	6995169	Bricka	Washer	
12	1	6995237	Nållager	Needle Bearing	
13	1	6995200	Kolv	Piston	
14	1	6995172	Kolvbult	Piston Pin	
15	2	6995171	Låsring	Washer, Piston Pin	
16	1	6995201	Kolvring	Piston Ring	
17	1	6995245	Cylinder	Cylinder Assy	
18	1	6995186	Stabilisator	Stabilizer	
19	4	6995252	Skruv	Screw	
20	1	6995248	Tätningssring	Seal Ring	
21	4	6995229	Skruv	Screw	
22	1	6995185	Packning	Muffler Gasket	
23	1	6995246	Ljuddämpare	Muffler	
24	1	6995251	Plåt	Plate	
25	2	6995182	Skruv	Screw	
26	1	6995210	Jordkabel	Earth Cable	
27	1	6995227	Stoppkabel	Stop Wire	
28	2	6995234	Skruv	Screw	
29	1	6995209	Elektronikspole	Electronic Coil	
30	1	6995022	Tändstiftsfjäder	Spark Plug Spring	
31	1	6995066	Tändstiftshatt	Spark Plug Cover	
32	2	6995238	Bussning	Bushing	
33	1	3210024	Tändstift	Spark Plug	
34	1	6995183	Insugningsrör	Intake Manifold Assy	
35	2	6995167	Skruv	Screw	
36	1	6995212	Packning	Gasket	
37	1	6995244	Förgasare	Carburettor	
38	1	6995214	Gummihylsa	Grommet	
39	1	6995213	Chokearm	Choke Lever Rod	
40	1	6995243	Luftfilterstöd	Air Filter Support	
41	2	6995168	Skruv	Screw	
41	1	6995211	Platta	Plate	
43	1	6995217	Luftfilter	Air Filter	
44	1	6995216	Luftfilterlock	Air Cleaner Cover	
51	2	23878008/0	Skruv	Screw	
52	1	6995175	Kåpa-främre	Front Cover	
53	1	6995239	Vevhus	Crankcase Ass.Y	
54	2	6995187	Skruv	Screw	
55	1	6995221	Vevhusventil	Breather Valve Ass.Y	
56	1	6995232	Gummihylsa	Grommet	
57	2	6995193	Lock	Cap Ass'Y	
58	1	6995228	Primer	Air Purge	
59	1	6995188	Gummihylsa kpl	Grommet Ass.Y	
60	1	6995189	Gummihylsa	Grommet	
61	1	6995174	Bränslefilter	Fuel Pickup Assy	
62	1	6995190	Bränsleledning	Tube	
63	2	23878008/0	Skruv	Screw	
64	1	6995249	Kåpa-övre	Upper Cover	
65	1	6995194	Skydd	Guard	
66	1	6995180	Kedjestopp	Chain Guard	
67	1	6995179	Skruv	Screw	
71	1	6995204	Packning	Gasket	
72	1	6995223	Bricka	Washer	
73	1	6995191	Oljefilter m.rör	Filter Intank Assy With Pipe	
74	1	6995242	Oljepump kpl	Oil Pump Assy	
75	1	6995222	Skruvhylsa	Female Screw	
76	1	6995205	Rör	Tube	
77	2	6995008	Skruv	Screw	
78	1	6995206	Pumplock	Cover Pump	
79	2	23878008/0	Skruv	Screw	
80	1	6995230	Nållager	Needle Bearing	
81	1	6995176	Kopplingshjul	"Drum Ass'Y, Clutch 3/8""	
81	1	6995178	Kopplingshjul	"Drum Ass'Y, Clutch 1/4""	
82	1	6995203	Bricka	Sprocket Washer	
83	1	6995177	Koppling	Clutch Ass.Y	





SPR 270 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
84	1	6995241	Plåt	Plate	
85	1	6995220	Ventil	Valve	
86	1	6995192	Packning	Gasket	
87	1	23275005/0	Dämpement	Shock Absorber	
88	1	23878007/0	Skruv	Screw	
89	1	23790006/0	Lock	Cap	
90	1	6995219	Klämma	Clamp	
91	1	23878009/0	Skruv	Screw	
92	1	6995231	Slangklämma	Fair Led	
93	1	6995184	Rör	Tube	
94	1	6995235	Rörförbindning	Tube Connection	
95	1	6995181	Skruv	Screw	





SPR 270 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	83058007/0	Start kpl-gul	Starter Assy Yellow	
2	1	23234000/0	Startsnöre	Starter Cord	
3	1	3750067	Starthandtag	Starter Handle	
4	1	23430557/0	Startfjäder	Starter Spring	
5	1	23604001/0	Linhjul	Starter Pulley	
6	1	23657002/0	Bricka	Washer	
7	1	23878010/0	Skruv	Screw	
8	1	23107501/0	Luftledare	Air Conveyor	
9	1	23878008/0	Skruv	Screw	
10	1	23275004/0	Gummihylsa	Grommet	
11	1	6995240	Handtag kpl	Handle Assy	
12	1	6995114	Fjäder	Spring	
13	1	6995134	Gasreglage	Throttle Lever	
14	1	6995016	Spännstift	Pin	
15	1	6995196	Lock	Cap	
16	1	23275005/0	Dämpement	Shock Absorber	
17	1	23878007/0	Skruv	Screw	
18	1	23790006/0	Lock	Cap	
19	1	6995226	Brytare	Switch	
20	1	6995198	Rör	Tube	
21	2	6995199	Rörförbindning	Tube Connection	
22	2	6995197	Rör	Tube	
23	1	6995218	Kåpa-bakre	Rear Cover	
24	1	6995215	Gasreglagelänk	Throttle Rod	
25	1	6995135	Säkerhetsspärr	Safety Lever	
26	1	6995195	Styre-överdel	Handle, Upper Part	
27	1	23878008/0	Skruv	Screw	
28	4	23878008/0	Skruv	Screw	
31	1	23790006/0	Lock	Cap	
32	1	23878007/0	Skruv	Screw	
33	1	23275005/0	Dämpement	Shock Absorber	
34	1	23105000/0	Handtag	Handle	
35	2	23878010/0	Skruv	Screw	
36	1	23200001/0	Platta	Plate	
37	1	23878010/0	Skruv	Screw	
41	1	23878009/0	Skruv	Screw	
42	1	23311003/0	Svärdplåt	Bar Plate	
43	1	23796004/0	Mutter	Bar Adjusting Block	
44	1	23878005/0	Skruv	Screw	
45	1	23510093/0	Sprint	Pin	
46	1	23448001/0	Bromsband	Brake Band	
47	1	23665001/0	Stift	Pin	
48	1	23430561/0	Fjäder	Spring	
49	1	23315061/0	Arm	Lever	
50	1	23430560/0	Fjäder	Spring	
51	1	23120000/0	Mutter	Nut	
52	1	23657003/0	Bricka	Washer	
53	1	23044206/0	Bussning	Bushing	
54	1	23455005/0	Handskydd	Hand Guard	
55	1	23430559/0	Fjäder	Spring	
56	1	83315050/0	Kedjebromsarm	Chain Brake Lever	
57	1	23665000/0	Stift	Roller	
58	1	23044207/0	Bussning	Bushing	
59	1	23430558/0	Fjäder	Spring	
60	1	23080000/0	Motvikt	Balance Weigth	
61	1	23878006/0	Skruv	Screw	
62	3	23878009/0	Skruv	Screw	
63	1	23109515/0	Bromskåpa	Brake Cover	
64	1	23059008/0	Kopplingshus-gul	Clutch Housing Yellow	
65	1	3641380	Bussning	Bushing	
66	1	2670120	Mutter	Nut	
71	1	123900114/0	Svärd	Guide Bar 12"	12" 3/8" mini .050" (1.3mm)
71	1	23900300/0	Svärd	Guide Bar 10"	10" 3/8" mini .050" (1.3mm)
71	1	23900301/0	Svärd	Guide Bar 10"	10" Carving 1/4" mini .050" (1.3mm)
72	1	4113281	Kedja (45E)	Chain 12"	12" 3/8" .050" (1.3 mm) - 45E
72	1	4113709	Kedja (4E)	Chain 10"	10" 3/8" .050" (1.3 mm) - 40E
72	1	4113760	Kedja (6E)	Chain 10"	10" 1/4" .050" (1.3 mm) - 60E
73	1	23085000/0	Kedjeskydd	Chain Cover	