


# Genuine Spare Parts


---



Joist  
Spareparts  
Joist



Utgåva Issue		Bildnr Picture No		COLLECTOR 45S COMBI E	COLLECTOR 45S COMBI E	Sida Page		
2004-12		1710				84		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2368							
	1	1		1117-1308-01	Kåpa- gul .....	Deck- yellow .....		
	2	1		1117-3007-01	Ledplåt- främre .....	Baffle- front .....		
	3	1		1117-3008-01	Ledplåt- bakre .....	Baffle- rear .....		
	4	1		1111-2927-01	Batterihållare .....	Battery holder .....		
	5	4		1117-1131-01	Flänsmutter .....	Nut .....		
	6	4		1117-3046-01	Bult .....	Bolt .....		
	7	4		9699-0062-02	Planbricka .....	Flat washer .....		
	8	2		1117-1192-01	Isolerplatta .....	Isolation .....		
X	9	1		1136-1430-01	Styre- underdel .....	Handlebar- lower part .....		
	10	2		9799-0831-02	Mutter .....	Nut .....		
	11	2		1117-3194-01	Lås ratt .....	Locking knob .....		
	12	2		1136-0693-01	Bricka .....	Washer .....		
	13	2		1136-0620-01	Skruv .....	Screw .....		
X	14	1		1136-1436-01	Styre- överdel .....	Handlebar- upper part .....		
	25	1		1117-1156-01	Lucka- gul .....	Rear flap- yellow .....		
	26	1		1117-1126-01	Fjäder .....	Spring- rear flap .....		
	27	1		1117-1143-01	Axel .....	Shaft .....		
	28	1		1117-1155-01	Luckinfästning- gul .....	Flap holder- yellow .....		
	29	2		9836-9516-12	Skruv .....	Screw .....		
	30	1		1117-1147-01	Transmissionskåpa .....	Transmission cap .....		
	31	2		9836-9516-12	Skruv .....	Screw .....		
X	41	1		1136-1535-01	Skrusats .....	Screw set .....		
X	102	1		1136-1424-01	Hållare- hö .....	Holder- R.H. ....		
X	103	1		1136-1421-01	Manöverdosa .....	Switch .....		
X	104	3		1136-1419-01	Skruv .....	Screw .....		
	105	3		9699-0060-02	Planbricka .....	Flat washer .....		
	106	3		1136-0693-01	Bricka .....	Washer .....		
X	107	1		1136-1422-01	Kabelhållare .....	Cable holder .....		
	108	1		1136-0662-01	Kabelhållare .....	Fairlead .....		
X	109	1		1136-1429-01	Manöverbygel .....	Control lever .....		
X	110	1		1136-1425-01	Hållare- vä .....	Holder- L.H. ....		
X	111	1		1136-1426-01	Hållare .....	Holder .....		
	231	1		1117-3001-01	Mulcherplugg .....	Mulch plug .....		
	272	2		1117-1213-01	Hålplåt .....	Sector .....		
	273	2		9716-0831-02	Mutter .....	Nut .....		
	274	6		9836-9516-12	Skruv .....	Screw .....		
	275	2		9836-9512-12	Skruv .....	Screw .....		
	276	2		1117-1131-01	Flänsmutter .....	Nut .....		
	278	2		1117-1228-01	Inställningsspak .....	Adjusting lever .....		
	279	2		1117-1376-01	Hjulsköld .....	Wheel lever .....		
	280	2		1117-1182-01	Ansatsbult .....	Shoulder bolt .....		
	281	2		9699-0062-02	Planbricka .....	Flat washer .....		
	282	4		1111-3165-01	Bussning .....	Bushing .....		
	283	2		1111-3163-01	Hjul .....	Wheel .....		
	284	2		1111-3164-01	Hjulbult .....	Wheel axle bolt .....		
	285	2		1111-2804-01	Navkapsel- gul .....	Hub cap- yellow .....		
	287	1		1117-1174-01	Höjdinställningsspak .....	Height adjust lever .....		
	288	2		1117-3256-01	Hjulsköld .....	Wheel protection cap .....		
	289	2		9699-0037-02	Bricka .....	Washer .....		
	290	4		1111-1273-01	Bussning .....	Bushing .....		
	291	2		1111-2663-01	Hjul .....	Wheel .....		
	292	2		9699-0085-02	Planbricka .....	Flat washer .....		
X	293	2		1136-1397-01	Skruv .....	Screw .....		
	294	2		1111-2815-01	Navkapsel- gul .....	Hub cap- yellow .....		
	401	1		1117-1160-01	Bakaxel .....	Shaft- backside .....		
X	402	1		1136-1408-01	Transmission kpl .....	Transmission assy .....		
	405	1		1117-1120-01	Fjäder .....	Spring .....		
	406	2		9595-0212-00	Spännstift .....	Locating pin .....		
	407	2		9549-0053-00	Kullager .....	Ball bearing .....		
	408	2		9591-0011-00	Stift .....	Pin .....		
	410	2		1111-3256-01	Drivkil .....	Drive key .....		
	411	2		1111-3075-01	Kuggjul- plasthjul .....	Pinion- plastic wheel .....		
	412	4		1111-2830-01	Stödbricka .....	Support washer .....		



Utgåva Issue		Bildnr Picture No		COLLECTOR 45S COMBI E	COLLECTOR 45S COMBI E	Sida Page		
2004-12		1710				86		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2368							
X	413	2		1117-1083-01	Låsring .....	Safety ring .....		
X	414	1		1111-9114-01	Drivrem .....	Drive belt .....		
X	415	1		1117-3266-01	Remskiva .....	Pulley .....		
	416	1		1136-1417-01	Skruv .....	Screw .....		
	417	1		1136-1407-01	Kopplingswire .....	Clutch cable .....		
	418	1		1136-1399-01	Kabelhylsa .....	Cable protector .....		
	451	2		9836-9116-12	Skruv .....	Screw .....		
	453	1		1117-1386-02	Motoråpa- svart .....	Motor cover- black .....		
	454	1		1117-1369-01	Elmotor .....	El.motor .....		
	455	1		9400-0224-00	Kondensator .....	Capacitor .....		
	456	2		1136-1213-01	Skruv .....	Screw .....		
	457	3		9699-0028-02	Planbricka .....	Flat washer .....		
	458	3		9678-0009-02	Låsbricka .....	Lock washer .....		
	459	4		9799-0831-02	Mutter .....	Nut .....		
	460	4		9699-0062-02	Planbricka .....	Flat washer .....		
	462	3		1117-1361-01	Motorstöd .....	Motor support .....		
	463	1		9997-0880-16	Skruv .....	Screw .....		
	464	1		1117-1359-01	Klämma .....	Clamp .....		
	465	1		1117-1245-01	Kabelklämma .....	Cable clamp .....		
	466	1		9849-7819-16	Skruv .....	Screw .....		
	467	4		1117-1112-01	Bult .....	Bolt .....		
	468	1		1117-1372-01	Motorbrunn- gul .....	Motor mount- yellow .....		
	469	1		1117-1373-01	Motorskydd- gul .....	Motor cover- yellow .....		
	470	4		9716-0831-02	Mutter .....	Nut .....		
	471	1		9849-7819-16	Skruv .....	Screw .....		
	472	1		1117-1357-01	Fönster .....	Window for cap .....		
	501	1		1111-2787-02	Knivbult .....	Blade bolt .....		
	502	1		1117-1111-01	Knivbricka .....	Disc washer .....		
	503	1		1111-9117-01	Kniv .....	Blade .....		
	504	1		1117-1299-01	Fläkt .....	Impeller .....		
	505	1		1117-1151-01	Knivfäste .....	Blade mount .....		
	506	1		1117-1358-01	Skydd .....	Motor shaft protectio .....		
	601	1		1117-1157-01	Uppsamlarlock- gul .....	Grassbag cover- yellow .....		
	602	1		1117-1218-01	Uppsamlare- underdel .....	Lower grass bag .....		
	603	2		9836-9516-12	Skruv .....	Screw .....		