


Genuine Spare Parts



Joist
Spareparts
Joist



Utgåva Issue		Bildnr Picture No		COLLECTOR 48 EL	COLLECTOR 48 EL	Sida Page		
2006-12		2115				102		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	3266 -65							
X	1	1		1136-2413-01	Chassi-gul.....	Chassis- yellow		
	2	4		9799-0831-02	Mutter.....	Nut		
	3	4		1136-0666-01	Lås ratt.....	Knob		
	4	2		9747-0831-02	Mutter.....	Lock nut.....		
X	5	2		1136-2414-01	Platta- yttre.....	Plate- outer.....		
	6	2		1136-0683-01	Platta- inre.....	Plate- inside		
X	7	2		1136-2415-01	Skruv.....	Screw.....		
	8	2		9997-0840-16	Skruv.....	Screw.....		
	9	1		1111-3530-01	Fjäder- hö.....	Spring- RH		
	10	1		1136-0686-01	Lucka- svart.....	Stone guard- black.....		
	11	1		1111-3531-01	Fjäder- vä.....	Spring- LH.....		
	12	1		1136-0680-01	Pivotaxel.....	Pivot pin.....		
	13	1		1136-0661-01	Kabelhållare.....	Fairlead		
	14	1		1136-0758-01	Styre- underdel.....	Handle- lower.....		
	15	2		1136-0693-01	Bricka.....	Washer.....		
	16	2		1136-0620-01	Skruv.....	Screw.....		
	17	2		1136-0660-01	Dragavlastare.....	Anchor clamp.....		
	18	1		1111-3613-01	Manöverdosa.....	Switch.....		
	19	1		1136-0662-01	Kabelhållare.....	Fairlead		
	20	1		1136-1437-01	Styre- överdel.....	Handlebar- upper part.....		
X	21	1		1136-2416-01	Huv.....	Cover.....		
	22	2		9836-9525-12	Skruv.....	Screw.....		
X	23	1		1136-0603-01	Låsring.....	Snap ring.....		
X	30	1		1136-2417-01	Skruvsats.....	Screw outfit.....		
	234	1		1136-0665-01	Gummihylsa.....	Rubber insert.....		
	301	4		9799-0831-02	Mutter.....	Nut		
	302	4		9683-0030-02	Låsbricka.....	Lock washer.....		
	303	4		1136-0014-01	Bricka.....	Washer.....		
	304	4		1136-0696-01	Höjdinställn.sektor.....	Wheel adjust sector.....		
	305	4		1136-0754-01	Hjulstöd.....	Wheel support.....		
	306	4		1136-0744-01	Höjdinställningsspak.....	Height adjust lever.....		
	307	4		1136-0084-01	Distans.....	Spacer.....		
	308	4		9997-0830-16	Skruv.....	Screw.....		
	308A	4		9699-0028-02	Planbricka.....	Flat washer.....		
X	309	4		1136-2337-01	Hjul.....	Wheel.....		
	310	4		9699-0056-02	Planbricka.....	Flat washer.....		
	311	4		9739-0831-22	Mutter.....	Nut		
X	312	4		1136-2272-01	Navkapsel- gul.....	Hub cap- yellow.....		
	451	1		1136-1741-01	Kåpstöd.....	Cover support.....		
	452	4		1136-1682-01	Skruv.....	Screw.....		
	453	1		1136-1687-01	Elmotor.....	El. motor.....		1600W
	453A	1		1136-1689-01	• Fläkt.....	• Fan.....		
	453B	1		1136-0626-01	• Kondensator.....	• Condensor.....		16 uF
	454	4		9836-9635-12	Skruv.....	Screw.....		
	455	4		9683-0030-02	Låsbricka.....	Lock washer.....		
	456	4		9799-0831-02	Mutter.....	Nut		
	457	1		1136-1706-01	Fläns.....	Flange.....		
	458	1		1136-1739-01	Ventilationsskärm.....	Ventilation screen.....		
	459	4		1136-0617-01	Skruv.....	Screw.....		
	460	1		1136-1677-01	Kil.....	Key.....		
	501	1		1136-1725-01	Knivfäste.....	Hub.....		
	502	1		1111-9121-01	Kniv.....	Blade.....		
	503	2		9683-0030-02	Låsbricka.....	Lock washer.....		
	504	2		9997-0820-16	Skruv.....	Screw.....		
	505	1		1136-0752-01	Knivbult.....	Blade bolt.....		
	552	1		1136-0676-01	Uppsamlingkorg- övre.....	Grass box- upper.....		
	553	1		1136-0677-01	Uppsamlingkorg- undre.....	Grass box- lower.....		