

Genuine Spare Parts

www.stiga.com

SNOW STAR-SNOW MAX Model Year 2002/03

includes:

18-2820-23 Snow Star


18-2821-23 Snow Max

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


STIGA®




Utgåva Issue		Bildnr Picture No		SNOW STAR- SNOW MAX STYRE STÖDHJUL		SNOW STAR- SNOW MAX HANDLE SUPPORT WHEELS		Sida Page	
2002- 49		865A						2	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2820	2821							
650	1	1		1133-0958-01	Hjulaxel.....	Wheel axle.....			
651	2	2		9699-0030-02	Planbricka.....	Flat washer.....			
660	2	2		1812-1455-01	Hjul.....	Wheel.....			
661	2	2		9699-0030-02	Planbricka.....	Flat washer.....			
662	2	2		1133-1021-01	Låsring.....	Retaining ring.....			
740	1	1		1812-1457-01	Reglagewire- övre.....	Control cable- upper.....			
741	1	1		1133-0977-01	Wirefäste.....	Cable adjust bracket.....			
742	1	1		1812-1456-01	Reglagewire- nedre.....	Control cable- lower.....			
743	1	1		1133-0968-01	Wirehylsa.....	Clutch spring boot.....			
744	1	1		1812-1670-01	Fjäder.....	Spring.....			
750	1			1133-0984-01	Styre underdel.....	Lower handle.....			
750		1		1812-1492-01	Styre underdel.....	Lower handle.....			
751	4	4		9988-3532-12	Skruv.....	Screw.....			
752	4	4		9699-0028-02	Planbricka.....	Flat washer.....			
753	4	4		1812-0812-01	Låsmutter.....	Locking nut.....			
755	1	1		1812-1515-01	Fäste.....	Bracket.....			
756	1	1		1133-0262-01	Ansatsbult.....	Shoulder bolt.....			
757	1	1		1133-0059-01	Linhjul.....	Pulley.....			
759	1	1		1812-1758-01	Mutter.....	Nut.....			
760	1			1133-1009-01	Styre överdel.....	Upper handle.....			
760		1		1812-1527-01	Styre överdel.....	Upper handle.....			
761	1	1		1133-0972-01	Inkopplingshandtag.....	Control bail.....			
762	2	2		1133-1017-01	Skruv.....	Bolt.....			
763	2	2		1133-0933-01	Kupad bricka.....	Formed washer.....			
764	2	2		1133-0932-01	Lås ratt.....	T- knob.....			
765	2	2		9795-3631-02	Mutter.....	Nut.....			

X


Spareparts Joist





Utgåva Issue		Bildnr Picture No		SNOW STAR RAM BRÄNSLETANK		SNOW STAR FRAME FUEL TANK		Sida Page	
2002- 49		1093						4	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2820								
X	80	1		1812- 1438- 01	Ramhalva- hö.....	Side frame- R.H.....		Volym 0.95 lit.	
	81	1		1812- 1437- 01	Ramhalva- vä.....	Side frame- L.H.....			
	90	1		1812- 1431- 01	Stödstag.....	Support rod.....			
	91	2		9683- 0035- 02	Låsbricka.....	Lock washer.....			
	92	2		9795- 3731- 02	Mutter.....	Nut.....			
	100	1		1133- 0941- 01	Tankfäste.....	Fuel tank bracket.....			
	101	2		9988- 3519- 16	Skruv.....	Screw.....			
	102	2		1812- 1758- 01	Mutter.....	Nut.....			
	110	1		1133- 0954- 01	Bränsletank.....	Fuel tank.....			
	111	4		1133- 0939- 01	Skruv.....	Screw.....			
	112	1		1812- 1554- 01	Tanklock.....	Gas tank cap.....			
	113	1		1133- 0992- 01	Bränsleslang.....	Fuel line tubing.....			
	114	2		1812- 1487- 01	Slangklämma.....	Fuel line clamp.....			



Utgåva Issue		Bildnr Picture No		SNOW MAX RAM BRÄNSLETANK		SNOW MAX FRAME FUEL TANK		Sida Page	
2002- 49		955A						6	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2821								
80	1			1812- 1438- 01	Ramhalva- hö.....	Side frame- R.H.....		Volym 1.42 lit.	
81	1			1812- 1437- 01	Ramhalva- vä.....	Side frame- L.H.....			
90	1			1812- 1512- 01	Stödstag.....	Support rod.....			
91	2			9683- 0035- 02	Låsbricka.....	Lock washer.....			
92	2			9795- 3731- 02	Mutter.....	Nut.....			
100	1			1812- 1490- 01	Tankfäste.....	Fuel tank bracket.....			
101	2			9988- 3519- 16	Skruv.....	Screw.....			
102	2			1812- 0812- 01	Låsmutter.....	Locking nut.....			
107	2			9988- 3519- 16	Skruv.....	Screw.....			
108	4			9699- 0028- 02	Planbricka.....	Fiat washer.....			
109	2			1812- 0812- 01	Låsmutter.....	Locking nut.....			
110	1			1812- 1489- 01	Bränsletank.....	Fuel tank.....			
111	1			1812- 1565- 01	Tätningring.....	Foam ring.....			
112	1			1812- 1504- 01	Tanklock.....	Fuel tank cap.....			
113	1			1812- 1486- 01	Bränsleslang.....	Fuel line tubing.....			
114	1			1133- 0070- 01	Slangklämma.....	Fuel line clamp.....			
116	3			1812- 1487- 01	Slangklämma.....	Fuel line clamp.....			
117	1			1812- 1482- 01	Bränslefilter.....	Fuel filter.....			
118	1			1812- 1498- 01	Bränsleslang.....	Fuel line tubing.....			




Utgåva Issue		Bildnr Picture No		SNOW STAR-SNOW MAX REMTRANSMISSION MOTOR		SNOW STAR-SNOW MAX BELT TRANSMISSION ENGINE		Sida Page	
2002-49		954A						8	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2820	2821							
11	2	2		9988-3619-16	Skruv	Screw			
12	4	4		1812-1669-01	Bricka	Washer			
14	4	2		9699-0029-02	Planbricka	Flat washer			
25	2	2		1133-0976-01	Remstyrning	Belt guide			
28	2	2		9988-3625-16	Skruv	Screw			
33	1	1		1812-1671-01	Fjäder	Spring			
40	1	1		1812-1604-01	Spännarm	Idler arm			
41	1	1		9988-3613-16	Skruv	Screw			
42	1	1		1812-0811-01	Låsmutter	Locking nut			
45	1	1		1133-0936-01	Spännrulle	Idler pulley			
46	1	1		1133-0084-01	Vagnsbult	Carriage bolt			
47	1	1		9743-3721-32	Mutter	Nut			
70	1	1		1812-1399-01	Motorremskiva	Engine pulley			
71	1	1		9699-0062-02	Planbricka	Flat washer			
72	1	1		9987-5119-16	Skruv	Screw			
73	1	1		1812-1669-01	Bricka	Washer			
75	1	1		1812-9025-01	Drivrem	Drive belt			




Utgåva Issue 2002-49	Bildnr Picture No 868B	SNOW STAR KÅPOR	SNOW STAR COVERS	Sida Page 10
----------------------------	------------------------------	--------------------	---------------------	--------------------



Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2820								
X 120	1				1812-1384-01	Kåpa- nedre	Cover- bottom		
121	4				9988-3532-12	Skruv	Screw		
122	4				9699-0028-02	Planbricka	Flat washer		
124	4				1812-1758-01	Mutter	Nut		
126	1				1812-1396-01	Förgasarlock	Carburettor cover		
127	2				1133-0955-01	Skruv	Screw		
128	2				1133-1026-01	Snabbmutter	Speed nut		
130	1				1133-0962-01	Linhylsa	Grommet & rope guide		
131	1				1133-0995-01	Starthandtag	Starter grip		
140	1				1133-0956-01	Tändningslås	Ignition switch		
141	1				1134-2853-01	Bricka	Washer		
142	1				1134-2852-01	Mutter	Nut		
143	1				1134-2848-01	Tändningsnyckel	Ignition key		
145	1				1133-0949-01	Primernippel	Primer		
146	1				1133-0930-01	Primerslang	Primer hose		
147	1				9795-3531-02	Mutter	Nut		
150	1				1133-0957-01	Remskydd	Belt cover		
151	6				1812-0959-01	Bult	Bolt		
152	6				1812-0630-01	Mutter	Nut		
153	1				9988-3516-16	Skruv	Screw		
154	1				9699-0028-02	Planbricka	Flat washer		
155	1				1133-0942-01	Mutter	Nut		
157	3				1133-0955-01	Skruv	Screw		
158	1				9699-0028-02	Planbricka	Flat washer		
159	3				1133-1026-01	Snabbmutter	Speed nut		
170	1				1812-1557-01	Motorkåpa- övre	Cover- top		
171	3				1133-0955-01	Skruv	Screw		
172	2				9699-0028-02	Planbricka	Flat washer		
173	3				1133-1026-01	Snabbmutter	Speed nut		
174	1				1133-0952-01	Tätning	Housing seal strip		
175	1				1133-0953-01	Tätning	Chute seal strip		
180	1				1133-0961-01	Ljuddämparskydd	Muffler guard		
181	2				9988-3516-16	Skruv	Screw		
182	2				9699-0028-02	Planbricka	Flat washer		
183	2				1133-0942-01	Mutter	Nut		



Utgåva Issue		Bildnr Picture No		SNOW MAX KÅPOR	SNOW MAX COVERS	Sida Page		
2002-49		948B				12		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2821							
X	120	1		1812-1558-01	Kåpa- nedre	Cover- bottom		
	121	3		1133-0955-01	Skruv	Screw		
	122	1		1812-1516-01	Lock	Panel		
	123	2		1812-1684-01	Snabbmutter	Clip		
	124	3		1133-1026-01	Snabbmutter	Speed nut		
	125	1		1812-1517-01	Reglagepanel	Control panel		
	126	2		9988-3532-12	Skruv	Screw		
	127	2		9699-0028-02	Planbricka	Flat washer		
	128	2		1812-0812-01	Låsmutter	Locking nut		
	130	1		1133-0962-01	Linhylsa	Grommet & rope guide		
	140	1		1133-0956-01	Tändningslås	Ignition switch		
	141	1		1134-2853-01	Bricka	Washer		
	142	1		1134-2852-01	Mutter	Nut		
	143	1		1134-2848-01	Tändningsnyckel	Ignition key		
	145	1		1133-0949-01	Primernippel	Primer		
	146	1		1812-1496-01	Primerslang	Primer hose		
	147	1		9795-3531-02	Mutter	Nut		
	150	1		1812-1502-01	Remskydd	Belt cover		
	151	4		1812-0959-01	Bult	Bolt		
	152	4		1812-0630-01	Mutter	Nut		
	157	4		1133-0955-01	Skruv	Screw		
	159	4		1133-1026-01	Snabbmutter	Speed nut		
	170	1		1812-1571-01	Kåpa- övre	Cover- top		
	171	4		1812-0959-01	Bult	Bolt		
	172	4		1812-0630-01	Mutter	Nut		
	173	9		1133-0955-01	Skruv	Screw		
	176	6		1133-1026-01	Snabbmutter	Speed nut		
	181	1		1133-0955-01	Skruv	Screw		
	182	2		1133-1026-01	Snabbmutter	Speed nut		
	191	1		1812-1555-01	Starthandtag	Starter handle		




Utgåva Issue		Bildnr Picture No		SNOW STAR- SNOW MAX SNÖSKRUV	SNOW STAR- SNOW MAX AUGER	Sida Page		
2002- 49		866C				14		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2820	2821						
	1			1133- 0994- 01	Snöskruvhus	Auger housing.....		
		1		1812- 1503- 01	Snöskruvhus	Auger housing.....		
	4	4		9988- 3519- 16	Skruv	Screw		
	4	4		9699- 0028- 02	Planbricka.....	Flat washer.....		
X	4	4		1812- 1758- 01	Mutter.....	Nut		
	1			9988- 3516- 16	Skruv	Screw		
	1			1133- 0993- 01	Vridstopp.....	Stop bracket.....		
	1			1812- 1556- 01	Bricka	Washer.....		
	1			9743- 3521- 32	Mutter.....	Nut		
	1			1133- 0999- 01	Skrapskär	Scraper blade		
		1		1812- 1481- 01	Skrapskär	Scraper blade		
	3	3		1133- 1022- 01	Nit.....	Rivet.....		
	1	1		9988- 3519- 16	Skruv	Screw		
X	1	1		1812- 1758- 01	Mutter.....	Nut		
	1	1		1133- 1019- 01	Flänslager	Flange bearing.....		
	2	2		9988- 3525- 16	Skruv	Screw		
	2	2		9699- 0028- 02	Planbricka.....	Flat washer.....		
	2	2		9727- 3541- 22	Mutter.....	Nut		
	1			1133- 0966- 01	Snöskruv kpl.....	Auger assy		
		1		1812- 1488- 01	Snöskruv kpl.....	Auger assy		
	4	4		1133- 0964- 01	Snöskruvskär.....	Auger blade		Pos 520- 2
	20	20		1133- 0940- 01	Nit.....	Rivet.....		Pos 520- 6
	2	2		1133- 0960- 01	Centrumskär	Centre blade.....		Pos 520- 8
	1	1		1133- 0947- 01	Lager m. hållare.....	Bearing & plate		
	1	1		1133- 1000- 01	Lagerhållare.....	Retainer plate		
	2	2		9988- 3516- 16	Skruv	Screw		
	2	2		9699- 0028- 02	Planbricka.....	Flat washer.....		
X	2	2		1812- 1758- 01	Mutter.....	Nut		
	1	1		1812- 1400- 01	Remskiva.....	Pulley		




Utgåva Issue		Bildnr Picture No		SNOW STAR- SNOW MAX UTKAST SKYDD		SNOW STAR- SNOW MAX DISCHARGE CHUTE CHUTE GUARD		Sida Page	
2002- 49		949						16	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2820	2821							
580	1			1133- 0987- 01	Utkastring	Chute ring			
580		1		1812- 1491- 01	Utkastring	Chute ring			
581	4	4		1133- 1014- 01	Skruv	Screw			
582	4	4		1133- 1018- 01	Utkastledplåt	Chute guide			
583		1		1812- 1564- 01	Tätning	Foam			
590	1	1		1133- 1004- 01	Utkaströr	Lower chute			
591	2	2		9899- 3516- 16	Skruv	Screw			
592	2	2		1812- 1758- 01	Mutter	Nut			
595	1	1		1133- 0970- 01	Utkastskydd	Wire chute guide			
596	1	1		1133- 0944- 01	Fjäder	Torsion chute spring			
597	1	1		1133- 0945- 01	Fjäder	Torsion chute spring			
598	2	2		1133- 0937- 01	Hattlåsning	Acorn nut			
600	1	1		1133- 0967- 01	Utkastskärm	Upper chute			
601	1	1		1133- 0969- 01	Gångjärnsaxel	Hinge wire			
602	1	1		9899- 3632- 12	Skruv	Screw			
603	1	1		9699- 0029- 02	Planbricka	Flat washer			
604	1	1		1133- 0932- 01	Låsrott	T- knob			
605	1	1		9795- 3631- 02	Mutter	Nut			
606	1	1		1133- 1023- 01	Skruv	Screw			
607	1	1		9699- 0029- 02	Planbricka	Flat washer			
608	1	1		1812- 0811- 01	Låsmutter	Locking nut			

X

Spareparts Joist



Utgåva Issue		Bildnr Picture No		SNOW STAR INSTÄLLINGSVEV	SNOW STAR CHUTE ROD	Sida Page		
2002-49		1092				18		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2820							
850	1			1133-0989-01	Inställningsvev.....	Upper chute rod.....		
851	1			9699-0035-02	Planbricka.....	Flat washer.....		
852	1			9599-0054-02	Saxpinne.....	Cotter pin.....		
853	1			1133-0973-01	Kupad fjäderbricka.....	Curved spring washer.....		
855	1			9699-0035-02	Planbricka.....	Flat washer.....		
856	1			1133-0959-01	Handtag.....	Knob.....		
857	1			1812-0396-01	Låsning.....	Retainer.....		
860	1			1812-1553-01	Öglebult.....	Eye bolt.....		
861	1			1812-0203-01	Hylsa.....	Grommet.....		
863	1			9683-0035-02	Låsbricka.....	Lock washer.....		
864	1			9743-3721-32	Mutter.....	Nut.....		
870	1			1812-1493-01	Vevfäste.....	Chute rotation brkt.....		
871	2			9899-3622-16	Skruv.....	Screw.....		
872	2			9699-0029-02	Planbricka.....	Flat washer.....		
873	2			1812-1669-01	Bricka.....	Washer.....		
874	2			9795-3631-02	Mutter.....	Nut.....		



Utgåva Issue		Bildnr Picture No		SNOW MAX INSTÄLLINGSVEV	SNOW MAX CHUTE ROD	Sida Page		
2002-49		953				20		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2821							
850	1			1812-1500-01	Inställningsvev.....	Chute rod.....		
851	1			9699-0035-02	Planbricka.....	Flat washer.....		
852	1			9599-0054-02	Saxpinne.....	Cotter pin.....		
853	1			1133-0973-01	Kupad fjäderbricka.....	Curved spring washer.....		
854	1			1812-1495-01	Fäste.....	Chute crank bracket.....		
855	1			9699-0035-02	Planbricka.....	Flat washer.....		
856	1			1133-0959-01	Handtag.....	Knob.....		
857	1			1812-0396-01	Låsning.....	Retainer.....		
858	2			9899-3516-16	Skruv.....	Screw.....		
859	2			9699-0028-02	Planbricka.....	Flat washer.....		
860	2			9683-0030-02	Låsbricka.....	Lock washer.....		
861	2			9795-3531-02	Mutter.....	Nut.....		
870	1			1812-1493-01	Vevfäste.....	Chute rotation brkt.....		
871	2			9899-3622-16	Skruv.....	Screw.....		
872	2			9699-0029-02	Planbricka.....	Flat washer.....		
873	2			9683-0030-02	Låsbricka.....	Lock washer.....		
874	2			9795-3631-02	Mutter.....	Nut.....		