Genuine Spare Parts

Hydro-Gear Transmission Model Year 2002/03

includes:

1812-1800-01 Hydro-Gear Transmission 314-0410

• Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.


- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.









Utgåva Bildnr Issue Picture No 2002- 49 1541		TRANSMISSION TRA		DRO-GEAR ANSMISSION - 0410		Sida Page 122
Pos. An Fig. I	tal/Quantity	Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		$\begin{array}{c} 1139 - 2013 - 01\\ 1139 - 2014 - 01\\ 1139 - 2015 - 01\\ 1139 - 2015 - 01\\ 1139 - 2017 - 01\\ 1139 - 2017 - 01\\ 1139 - 2020 - 01\\ 1139 - 2023 - 01\\ 1139 - 2023 - 01\\ 1139 - 2023 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2025 - 01\\ 1139 - 2030 - 01\\ 1139 - 2005 - 01\\ 1139 - 2005 - 01\\ 1139 - 2050 - 01\\ 1139 $	Låsring Bricka	Washer Flat washer Screw Washer Friction puck. Ball bearing. Retaining ring. Stud Thrust bearing Spacer Cylinder block Gear Swash plate Bolt Washer Lip seal Pin By- pass actuator Ring magnet By- pass actuator Ring magnet Deflector By- pass spring Lip seal Fitting Hose Lip seal Fitting Hose Lip seal Fitting Hose Lip seal Pulley Screw Main housing assy Scheck plug Bearing Motor shaft Input shaft Tube- bull gear assy. By- pass arm Lip seal Motor shaft Input shaft Tube- bull gear assy By- pass arm Lip seal Motor shaft Input shaft Tube- bull gear assy By- pass arm Lip seal Motor shaft Retaining ring Screw Retaining ring Compression spring Washer Pin Plug Center section- filter Filter assy Expansion tank kit		10T 10T/48T 13T Pos 25,31- 33,42,45 Inkl. pos 25,31- 33 Inkl. pos 27,37,54,61

Reservdelskatalog

/TIG-N[®]

TRANSMISSION