Genuine Spare Parts

Light kit Model Year 2002/03


includes: 18-1914-13 Light kit/Belysningssats

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permision in writing from GLOBAL GARDEN PRODUCTS.









TILLBEHÖR ACCESSORIES

Parts Catalogue					/ IIGA					ACCESSORIES	
Utgåva Issue		Bildnr Picture No			BELYSNINGSSATS ART.NR 18- 1914- 13			HT KIT NO 18-1914-13	Sida Page		
2002-49		1091							112		
Pos. Fig.	Ar	ntal/Q	l/Quantity		Art nr Part No	Benämning	•	Description	Sats Kit	Anmärkning Notes	
	1914										
1 2 3 3 A 3 B 3 C 3 D 4 5 6 7 8 9 10 11 12 13	1 1 1 1 1				1812-1584-01 1812-1478-01 1812-1195-01 1812-1196-01 1812-1245-01 1812-1197-01 1812-1169-01 1812-1582-01 1133-0220-01 1812-0659-01 9683-0030-02 9795-3631-02 1812-0963-01 1812-0808-01 1812-1583-01	Lamphållare Kabelhärva Skruv Kabelhållare		Housing-lower Headlight assy Lens cover Light housing Lamp holder Wire harness Screw Wire tie Light bracket Lock washer			