Genuine Spare Parts

Hydro-Gear Transmission Model Year 2003/04

includes:


1812-1800-01 Hydro-Gear Transmission 314-0410

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permision in writing from GLOBAL GARDEN PRODUCTS.









TRANSMISSION TRANSMISSION

arts Catalogue						I KANSINISSIOI			
Utgåva Bildnr			-	HYDRO-GEAR TRANSMISSION TRANSMISSION				Sida	
Picture No 2003- 59 1541		Pic	Picture No		TRANSMISSION TRANSMISSION 314-0410				Page
			314-0410	130					
os.	Antal/Quantity			/	Art nr	Benämning	Description	Sats	Anmärkning
g.					Part No			Kit	Notes
	314- 0410								
1	2				1139-2011-01	Planbricka	Flat washer		
2	1				1139-2012-01	Låsring	Retaining ring		
3	1				1139-2013-01	Bricka	Washer		
4	1					Planbricka			
5	2					Skruv			
3	2					Bricka Friktionsbricka			
7 B	1					Kullager			
0	1			Į		Låsring	1		
1	1			İ	1139-2020-01	Pinnbult	Stud		
2	2					Trycklager	Thrust bearing		
3	1			1		Distans			
4	2					Cylinderblock Drev			10T
6 7	1					Stänkplatta			
9	1					Bult	•		
Ö	1					Bricka	Washer		
1	1					Tätningsring			
2	1					Axel			
5	1					By- pass aktiverare			
6 7	1 2					Magnet			
В	1				1139-2033-01				10T/48T
9	1					Drev	Pinion gear		13T
2	1					Deflektor			
3	1				1139-2036-01	• By- pass fjäder	• By- pass spring		
4	1					Tätningsring Nippel			
5 7	1 1		ľ			• Slang			
8	Ιi				1139-2040-01	Tätningsring			
9	l i				1139-2041-01	Remskiva	Pulley		
1	14					Skruv			
3	1			1		Huvudhus kpl			
4	1					Sidohus kpl			
5 6	2					Plugg Lager			
7	1					Motoraxel			
8	i					Ingående axel	Input shaft		
9	1		1			Rör- drev kpl			
0	1 1		1	1		By- pass stång			
1 2	1 2					By- pass arm Tätningsring			
3	1					Slang			
4						• Vikt	• Weight		
5	2	1			1139-2056-0°	l Bricka	Washer		
6	1					Expansionskärl			
7	2					1 Låsring			
8	1					1 Fäste 1 Reglagearm			
69 60						1 Regiageaiii 1 Fäste			
31	li					1 • Lock			
32] i			4	1139-2046-0	1 Skruv	Screw		
35	1	1			1139-2071-0	1 Låsring	Retaining ring		
66	1					1 Tryckfjäder	Compression sprin		
37	1					1 Bricka			
70 71	2					1 Sprint 1 Plugg			
71 20						1 Plugg 1 Centrumstycke- filter			Pos 25,31-33,42,45
21				1		1 Filter kpl			Inkl. pos 25, 31-33
	1 1					1 Expansionskärl kpl	Expansion tank kit .		Inkl. pos 27,37,54,61
28				1		1 Transportlock			İ