Genuine Spare Parts

Light kit Model Year 2003/04

includes:


18-1914-13 Light kit/Belysningssats

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permision in writing from GLOBAL GARDEN PRODUCTS.









TILLBEHÖR ACCESSORIES

Parts Catalogue						ACCESSORIES				
Utgåva E Issue F			Bildnr Picture No 1091		BELYSNINGSSATS ART.NR 18-1914-13		LIGHT KIT ART.NO 18- 1914- 13		Sida Page 124	
Pos. Fig.	Ar	ntal/Qu	antity	1	Art nr Part No	Benämning		Description	Sats Kit	Anmärkning Notes
1 2 3 3 E 5 6 7 8 9 10 11 12 13	1 1				1812-1584-01 1812-1478-01 1812-1195-01 1812-1196-01 1812-1245-01 1812-1197-01 1812-1169-01 1812-1582-01 1133-0220-01 1812-0659-01 9683-0030-02 9795-3631-02 1812-0963-01 1812-0808-01 1812-1583-01	Lamphus- övre		Housing- upper		