

Genuine Spare Parts




Joist
Spareparts
Joist

Utgåva Issue 2005-14		Bildnr Picture No 1765		SNOW BREEZE RS SNOW BREEZE ES STYRE HJUL		SNOW BREEZE RS SNOW BREEZE ES HANDLE WHEELS		Sida Page 12	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2825	2826							
1	1	1		1812-1989-01	Styre-överdel	Handle- upper			
2	1	1		1812-1961-01	Reglagebygel	Control bail			
3	1	1		1133-0968-01	Wirehylsa	Clutch spring boot			
4	1	1		1812-2002-01	Reglagewire	Control cable			
5	1	1		1133-0977-01	Wirefäste	Cable adjust bracket			
6	1	1		1812-1883-01	Reglagewire- nedre	Control cable- lower			
7	1	1		1812-1670-01	Fjäder	Spring			
8	2	2		1812-1973-01	U- bult	U- bolt			
9	2	2		1133-0933-01	Kupad bricka	Formed washer			
10	2	2		1812-1928-01	Lås ratt	Wing knob			
11	1	1		1812-1960-01	Styre- underdel	Handle- lower			
12	4	4		1812-0812-01	Låsmutter	Locking nut			
13	4	4		9699-0028-02	Planbricka	Flat washer			
14	4	4		9988-3532-12	Skruv	Screw			
21	2	2		1133-1021-01	Låsring	Retaining ring			
22	2	2		9699-0035-02	Planbricka	Flat washer			
23	2	2		1812-1455-01	Hjul	Wheel			
24	2	2		1812-1922-01	Distans	Spacer sleeve			
25	1	1		1812-1975-01	Hjulaxel	Axle rod			
26	2	2		9699-0030-02	Planbricka	Flat washer			
99	1	1		8218-2203-09	Bruksanvisning	Owner's manual		Ej ill/not ill.	

X


Joist Spareparts




Utgåva Issue		Bildnr Picture No		SNOW BREEZE RS SNOW BREEZE ES RAM BRÄNSLETANK		SNOW BREEZE RS SNOW BREEZE ES FRAME FUEL TANK		Sida Page
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2825	2826						
1	4	4		9988-3519-16	Skruv	Screw		
2	4	4		9699-0028-02	Planbricka	Flat washer		
3	1	1		1812-2055-01	Fäste	Bracket		
4	1	1		1812-1906-01	Tanklock	Fuel tank cap		
5	1	1		1812-1971-01	Bränsletank	Fuel tank		
6	8	8		1812-0812-01	Låsmutter	Locking nut		
7	3	3		1812-0811-01	Låsmutter	Locking nut		
8	2	2		1812-1998-01	Bränsleslang	Fuel line tubing		
9	3	3		1812-1487-01	Slangklämma	Fuel line clamp		
10	1	1		1812-1907-01	Bränslefilter	Fuel line filter		
12	1	1		1812-1954-01	Motorvagga	Engine cradle		
13	1	1		1812-1968-01	Ram- vä	Frame- LH		
14	1	1		9988-3616-16	Skruv	Screw		
15	4	4		9988-3551-12	Skruv	Screw		
16	2	2		1812-1894-01	Platta	Bolting support plate		
17	1	1		1812-1955-01	Ramstöd	Frame support		
18	1	1		1812-1967-01	Ram- hö	Frame- RH		
19	2	2		9988-3619-16	Skruv	Screw		
20	1	1		1812-1943-01	Skumplastring	Foam ring		
21	1	1		1133-0070-01	Slangklämma	Fuel line clamp		
22	2	2		9988-3516-16	Skruv	Screw		

X

Joist Spareparts




Utgåva Issue 2005-14		Bildnr Picture No 1767		SNOW BREEZE RS SNOW BREEZE ES REMTRANSMISSION MOTOR		SNOW BREEZE RS SNOW BREEZE ES BELT TRANSMISSION ENGINE		Sida Page 16	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2825	2826							
2	1	1		1812-1954-01	Motorvagga	Engine cradle			
3	1	1		1812-1968-01	Ram- vä	Frame- LH			
4	4	4		1812-1997-01	Avvibrering	Antivibration mount			
5	1	1		9988-3625-16	Skruv	Screw			
6	4	4		1812-1918-01	Skruv	Screw			
7	1	1		9699-0029-02	Planbricka	Flat washer			
8	4	4		1812-0811-01	Låsmutter	Locking nut			
9	1	1		1812-1893-01	Remstyrning	Belt guide			
10	1	1		1812-1829-01	Ansatsbult	Shoulder bolt			
11	1	1		1812-1891-01	Brombelägg	Brake pad			
12	1	1		9988-3516-16	Skruv	Screw			
13	1	1		1812-1882-01	Spännarm	Idler pivot arm			
14	1	1		1812-1885-01	Fjäder	Spring			
15	1	1		1812-0812-01	Låsmutter	Locking nut			
16	1	1		1812-1829-01	Ansatsbult	Shoulder bolt			
17	1	1		1812-1896-01	Bromsstång	Brake wire			
18	1	1		1812-1670-01	Fjäder	Spring			
19	1	1		1812-1879-01	Låsnål	Cotter pin			
20	1	1		1812-1888-01	Spännarm	Idler bracket arm			
21	1	1		1812-1881-01	Länkstäng	Clutch linkage rod			
22	1	1		1133-0936-01	Spännrulle	Idler pulley			
23	1	1		9988-3738-12	Skruv	Screw			
24	1	1		1812-1977-01	Motorremskiva	Engine belt pulley			
25	1	1		1812-1976-01	Bult	Bolt			
26	1	1		9699-0028-02	Planbricka	Flat washer			
27	1	1		9988-3551-12	Skruv	Screw			
28	1	1		1812-1897-01	Rulle	Pinch roller			
29	1	1		1812-1880-01	Planbricka	Flat washer			
30	1	1		9743-3721-32	Mutter	Nut			
31	1	1		1812-1878-01	Drivrem	Drive belt			
32	2	2		9988-3651-12	Skruv	Screw			
33	2	2		9988-3725-16	Skruv	Screw			
34	1	1		9699-0079-02	Bricka	Washer			
35	8	8		9683-0030-02	Låsbricka	Lock washer			
36	4	4		9795-3631-02	Mutter	Nut			
41		2		1812-1923-01	Skruv	Screw			
42		2		9699-0079-02	Bricka	Washer			
43		2		1812-1921-01	Mutter	Nut			
46		1		1812-1615-01	Förlängningssladd	Extension cord			
47	1	1		1812-1995-01	Handtag	Grip			



Utgåva Issue		Bildnr Picture No		SNOW BREEZE RS SNOW BREEZE ES KÅPOR		SNOW BREEZE RS SNOW BREEZE ES COVERS		Sida Page	
2005-14		1768A						18	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2825	2826							
1	1	1		1812-1962-01	Reglagepanel.....	Control panel.....			
2	2	2		9988-3532-12	Skruv.....	Screw.....			
3	4	4		9699-0028-02	Planbricka.....	Flat washer.....			
4	2	2		1812-0812-01	Låsmutter.....	Locking nut.....			
5	1	1		1812-1970-01	Bussning.....	Chute crank bushing.....			
6	1	1		1134-2852-01	Mutter.....	Nut.....			
7	1	1		1134-2848-01	Tändningsnyckel.....	Ignition key.....			
8	1	1		1812-1905-01	Primernippel.....	Primer bulb.....			
9	1	1		1812-1974-01	Lock.....	Cover.....			
10	1	1		9795-3531-02	Mutter.....	Nut.....			
11	1	1		1812-1496-01	Primerslang.....	Primer hose.....			
12	1	1		1133-0956-01	Tändningslås.....	Ignition switch.....			
13	1	1		1812-1960-01	Styre- underdel.....	Handle-lower.....			
14	13	13		1133-0955-01	Skruv.....	Screw.....			
15	11	11		1133-1026-01	Snabbmutter.....	Speed nut.....			
16	1	1		1812-1965-01	Kåpa- undre.....	Bottom cover.....			
17	1	1		1812-1996-01	Remskydd.....	Belt cover.....			
18	8	8		1812-0959-01	Bult.....	Bolt.....			
19	6	6		1812-0630-01	Mutter.....	Nut.....			
20	2	2		1812-1758-01	Mutter.....	Nut.....			
21	2	2		9988-3516-16	Skruv.....	Screw.....			
22	1	1		1812-1993-01	Kåpa- övre.....	Top cover.....			
24	1	1		1134-2853-01	Bricka.....	Washer.....			
25	1	1		1812-1966-01	Lock.....	Oil access cover.....			
26	1	1		1812-1987-01	Packning.....	Gasket.....			
27	6	6		1812-1916-01	Snabbmutter.....	Push nut.....			
28	1	1		1812-2018-01	Kabelklämma.....	Cable clamp.....			

X



Utgåva Issue 2005-14		Bildnr Picture No 1769		SNOW BREEZE RS SNOW BREEZE ES SNÖSKRUV		SNOW BREEZE RS SNOW BREEZE ES AUGER		Sida Page 20	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2825	2826							
1	2	2		9988-3525-16	Skruv	Screw			
2	8	8		1812-0812-01	Låsmutter	Locking nut			
3	3	3		9988-3519-16	Skruv	Screw			
4	10	10		9699-0028-02	Planbricka	Flat washer			
5	1	1		1812-1956-01	Snöskruvhus	Auger housing			
6	2	2		9988-3516-16	Skruv	Screw			
7	1	1		1812-1984-01	Snöskruv	Auger			
8	1	1		1812-1925-01	Lagerhållare	Bearing retainer			
9	1	1		1812-1383-01	Kullager	Ball bearing			
10	1	1		1812-1895-01	Distans	Sleeve spacer			
11	1	1		1133-1000-01	Lagerhållare	Retainer plate			
12	1	1		1812-1889-01	Remskiva	Pulley			
13	1	1		1133-1019-01	Flänslager	Flange bearing			

Utgåva Issue		Bildnr Picture No		SNOW BREEZE RS SNOW BREEZE ES UTKAST INSTÄLLINGSVEV		SNOW BREEZE RS SNOW BREEZE ES DISCHARGE CHUTE CHUTE ROD		Sida Page	
2005- 14		1770A						22	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2825	2826							
X	1	7	7	1133-0955-01	Skruv	Screw			
X	2	1	1	1812-2057-01	Hållare	Chute ring retainer			
	3	1	1	1812-2058-01	Utkastring	Chute ring			
	4	2	2	9899-3622-16	Skruv	Screw			
	6	1	1	1812-1953-01	Fäste-utkast	Chute neck			
	7	1	1	1812-1979-01	Utkastskärm	Upper chute			
	8	1	1	1812-1928-01	Låsrratt	Wing knob			
	9	2	2	9699-0029-02	Planbricka	Flat washer			
	10	1	1	9678-0010-02	Låsbricka	Starlock			
	11	1	1	1812-0811-01	Låsmutter	Locking nut			
	12	1	1	1812-1678-01	Vagnsbult	Carriage bolt			
	13	1	1	1812-1978-01	Bult	Bolt			
	14	2	2	9699-0035-02	Planbricka	Flat washer			
	15	2	2	9743-3621-32	Mutter	Nut			
	16	1	1	1812-1994-01	Utkaströr	Lower chute			
	18	1	1	1812-1706-01	Drev	Gear			
	19	2	2	1812-1924-01	Skruv	Screw			
	20	1	1	1812-0396-01	Låsning	Retainer			
	21	1	1	1133-0959-01	Handtag	Knob			
	22	1	1	9699-0035-02	Planbricka	Flat washer			
	23	1	1	1812-1927-01	Vev	Chute rotation crank			
	25	2	2	1812-1791-01	Låsnål	Hair pin			
	26	1	1	1812-1708-01	Gaffel	Yoke adapter			
	27	1	1	9599-0033-00	Saxsprint	Split pin			
	28	1	1	1812-1316-01	Axel	Universal pin			
	29	1	1	1812-1318-01	Sprint	Clevis pin			
	30	1	1	1812-1317-01	Ledknut	Universal pivot block			
	31	1	1	1812-1969-01	Gaffelstång	Crank rod			
	32	4	4	9988-3519-16	Skruv	Screw			
	33	1	1	1812-1963-01	Skrapskär	Scraper blade			
	34	4	4	1812-1758-01	Mutter	Nut			
	595	1	1	1133-0970-01	Utkastskydd	Wire chute guide			
	596	1	1	1133-0944-01	Fjäder	Torsion chute spring			
	597	1	1	1133-0945-01	Fjäder	Torsion chute spring			
	598	2	2	1133-0937-01	Hattlåsning	Acorn nut			