


# Genuine Spare Parts

---



Spareparts  
Joist



Utgåva Issue		Bildnr Picture No		HYDRO- GEAR TRANSMISSION 317- 0410		HYDRO- GEAR TRANSMISSION 317- 0410		Sida Page 104	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	317- 0410								
X 9	1				1812-2238-01	Ingående axel .....	Input shaft.....		
X 10	1				1812-2158-01	Låsring .....	Retaining ring .....		
X 11	1				1812-2169-01	Distans .....	Spacer .....		
X 12	1				1812-2239-01	Låsring .....	Retaining ring .....		
X 13	1				1812-2240-01	Tätning .....	Seal .....		
X 14	1				1812-2170-01	Kullager .....	Ball bearing .....		
X 55	1				1812-2156-01	Fjäder.....	Spring .....		
X 56	1				1812-2157-01	Tryckbricka .....	Thrust washer .....		
X 120	1				1812-2241-01	Remskiva.....	Pulley .....		
X 121	1				1812-2242-01	Skruv .....	Screw .....		
X 122	1				1812-2151-01	Bricka .....	Washer .....		
X 127	1				1812-2243-01	Tätningringsats .....	Seal & o- ring kit .....		
X 128	1				1812-2244-01	Expansionskärl kpl.....	Expansion tank assy.....		