



Genuine Spare Parts




Joist
Spareparts
Joist



Utgåva Issue		Bildnr Picture No		SNOW ELECTRIC 2000 STYRE		SNOW ELECTRIC 2000 HANDLE		Sida Page	
2008- 14		2322						2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2806 -29								
7	4			1811-2301-01	Skruv	Screw			
36	2			1811-2360-01	Hjul	Wheel			
37	1			1811-2379-01	Hjulaxel	Wheel shaft			
38	6			9650-0012-04	Seegersäkring	Circlip			
39	6			9699-0115-02	Bricka	Washer			
40	2			9849-8032-16	Skruv	Screw			
41	1			1811-2373-01	Hjulplåt- vä.	Wheel plate- LH			
42	1			1811-2374-01	Hjulplåt- hö	Wheel plate- RH			
43	4			1716-0003-01	Skruv	Screw			
44	4			9997-0535-12	Skruv	Screw			
45	4			9747-0531-02	Mutter	Nut			
46	1			1811-2383-01	Styre- underdel	Handle- lower			
47	4			1716-0224-01	Plugg	Plug			
48	2			1716-0225-01	Kabelhållare	Cable holder			
49	1			1811-2382-01	Styre- mellandel	Handle- middle			
50	4			1811-2317-01	Lås ratt	Locking knob			
51	1			1811-2381-01	Styre- överdel	Handle- upper			
52	1			1811-2349-01	Brytare	Switch			
53	1			1716-0192-01	Kabelhållare	Cable- kink protection			
99	1			8218-2218-80	Bruksanvisning	Owner's manual		Ej ill/not ill.	



Utgåva Issue		Bildnr Picture No		SNOW ELECTRIC 2000 TRANSMISSION		SNOW ELECTRIC 2000 TRANSMISSION		Sida Page	
2008- 14		2323						4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2806								
	-29								
7	5			1811-2301-01	Skruv.....	Screw.....			
30	1			1811-2322-01	Remskiva.....	Drive wheel.....			
31	1			9948-0616-16	Skruv.....	Screw.....			
32	1			9699-0060-02	Planbricka.....	Flat washer.....			
33	1			9683-0025-02	Låsbricka.....	Lock washer.....			
34	1			1811-2356-01	Drivrem.....	Drive belt.....			
35	1			1811-2371-01	Remskydd.....	Belt cover.....			
54	1			1811-2367-01	Chassi.....	Chassis.....			
55	1			1811-2339-01	Fjäder- spännarm.....	Spring- tension arm.....			
56	1			1811-2338-01	Spännrullaxel.....	Tension roller shaft.....			
57	2			1811-2300-01	Kullager.....	Ball bearing.....			
58	1			1811-2364-01	Spännrulle.....	Strain wheel.....			
59	1			1811-2350-01	Låsring.....	Snap ring.....			
60	1			9699-0028-02	Planbricka.....	Flat washer.....			
61	1			1811-2324-01	Remskiva- motor.....	Main drive wheel.....			
62	1			9683-0030-02	Låsbricka.....	Lock washer.....			
63	1			9799-0831-02	Mutter.....	Nut.....			
64	1			1811-2341-01	Spännarm.....	Tension arm.....			
65	1			1811-2355-01	Nit.....	Rivet.....			
66	3			9683-0025-02	Låsbricka.....	Lock washer.....			
67	1			9699-0028-02	Planbricka.....	Flat washer.....			
68	3			9747-0631-02	Låsmutter.....	Lock nut.....			
69	1			1811-2380-01	Motorplatta.....	Motor base.....			
70	1			1811-2345-01	Motorgavel- främre.....	End plate- front.....			
71	1			1811-2346-01	Motorgavel- bakre.....	End plate- rear.....			
72	4			1811-2354-01	Bult.....	Bolt.....			L = 110 mm
73	4			9683-0015-02	Låsbricka.....	Lock washer.....			
74	1			1811-2376-01	Stator.....	Stator.....			
75	1			1811-2375-01	Rotor.....	Rotor.....			
76	2			9549-0019-00	Kullager.....	Ball bearing.....			
77	1			1811-2304-01	Packning.....	Wave gasket.....			
78	2			9997-0625-16	Skruv.....	Screw.....			
79	1			1811-2359-01	Fläkt.....	Fan.....			
80	1			9650-0015-04	Låsring.....	Lock ring.....			
81	1			1716-0129-01	Kondensator.....	Capacitor.....			
82	1			9683-0030-02	Låsbricka.....	Lock washer.....			
83	1			1811-2357-01	Kabelklämma.....	Wire clip.....			
84	1			1811-2365-01	Fäste.....	Flashboard.....			
85	1			1811-2306-01	Gummihylsa.....	Rubber grommet.....			



Utgåva Issue		Bildnr Picture No		SNOW ELECTRIC 2000 SNÖSKRUV	SNOW ELECTRIC 2000 AUGER	Sida Page			
2008-14		2324				6			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2806 -29								
1	1			1811-2310-01	Utkastskärm	Upper outlet			
2	2			9699-0060-02	Planbricka.....	Flat washer.....			
3	2			9898-0635-12	Skruv	Screw.....			
4	2			1811-2317-01	Låsratt	Locking knob			
5	1			1811-2311-01	Utkaströr	Lower outlet.....			
6	1			1811-2352-01	Rensdon	Cleaner stick			
7	2			1811-2301-01	Skruv	Screw.....			
8	7			9847-8016-16	Skruv	Screw.....			
9	1			1811-2372-01	Kåpa- gul	Cover- yellow			
10	1			1811-2370-01	Inmatningshus- gul.....	Snow channel- yellow			
11	1			1811-2363-01	Spärr	Block			
12	2			1811-2332-01	Fjäder.....	Spring			
13	1			1811-2368-01	Krage- gul	Cuff- yellow			
14	1			1811-2369-01	Skydd- gul	Dust proof cover- yell.....			
15	3			9847-7913-16	Skruv	Screw.....			
16	6			9950-0510-16	Skruv	Screw.....			
17	15			9699-0024-02	Planbricka.....	Flat washer.....			
18	2			1811-2337-01	Lagerskål- yttre.....	Bearing cover- outer.....			
19	2			9549-0044-00	Kullager	Ball bearing			
20	2			1811-2343-01	Lagerskål- inre	Bearing cover- inner.....			
21	1			1811-2361-01	Snöskruvfäste- vä	Propeller brkt- LH.....			
22	1			1811-2362-01	Snöskruvfäste- hö.....	Propeller brkt- RH.....			
23	16			9948-0616-16	Skruv	Screw.....			
24	16			9747-0631-02	Låsmutter	Lock nut.....			
25	2			1811-2358-01	Kil	Shaft key			
26	2			1811-2377-01	Gummipaddel	Rubber wheel			
27	1			1811-2378-01	Snöskruvaxel	Prop plate & shaft			
28	4			9650-0017-04	Låsring	Retaining ring			
29	1			1811-2366-01	Skrapskär- gul	Spading board- yellow.....			